

# NORTHERN PACIFIC RAILWAY COMPANY.

## TACOMA DIVISION

# TIME 35A TABLE

In Effect at 12:01 A. M. Pacific or 120th Meridian Time.

(One hour slower than Mountain or 105th Meridian Time.)

## SUNDAY, November 12th, 1911.

For the Government of Employes only. The Company reserves the right to vary therefrom at pleasure. Be positive that you have the Current Time Table and destroy all previous numbers. Read carefully the Special Rules and always have for reference a copy of TRANSPORTATION RULES.

**H. C. NUTT,**  
General Manager.

**I. B. RICHARDS,**  
General Superintendent.

**P. H. McCaULEY,**  
Superintendent of Transportation.

**W. C. ALBEE,**  
Superintendent.

**T. E. COYLE,**  
Assistant Superintendent.

**C. E. McMULLIN,**  
Superintendent Tacoma Terminals.

**J. C. ROTH,**  
Assistant Superintendent of Transportation.

West Bound.

MAIN LINE.

THIRD CLASS TRAINS.

SECOND CLASS

FIRST CLASS TRAINS.

Time Table 35A

Succeeding No. 85  
November 12, 1911.

STATIONS.  
Telegraph Offices and  
Calls

Distance from  
Tacoma Wharf

Main table with columns for train classes (973, 963, 997, 965, 691, 679, 355, 363, 301, 389, 361, 321, 307, 357, 391, 311, 369, 333, 365, 359, 313, 323, 393), days (EX. SUN., DAILY), times, station names, and distances.

MAIN LINE.

East Bound.

FIRST CLASS TRAINS.																	Distance from Portland	Time Table 35A Succeeding No. 85 November 12, 1911. <b>STATIONS.</b> Telegraph Offices and Calls	SECOND CLASS TRAINS.				THIRD CLASS TRAINS.			
<b>356</b>	<b>322</b>	<b>390</b>	<b>334</b>	<b>394</b>	<b>312</b>	<b>370</b>	<b>324</b>	<b>314</b>	<b>358</b>	<b>362</b>	<b>308</b>	<b>366</b>	<b>392</b>	<b>360</b>	<b>302</b>	<b>364</b>			<b>680</b>	<b>692</b>	<b>964</b>	<b>966</b>	<b>998</b>	<b>974</b>		
DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	EX. MON.	EX. SUN.	DAILY	EX. MON.			
Gt. Nor.	Nor. Pac. Grays Harbor Limited	Nor. Pac. Yacont Passenger	Nor. Pac. Evergreen State Limited	Nor. Pac. South Bend Limited	O.-W. R. & N. Shasta Limited	O.-W. R. & N. Ore-Wash Express	Nor. Pac. Grays Harbor Express	Nor. Pac. Seattle Special	Gt. Nor.	O.-W. R. & N. Seattle Passenger	Nor. Pac. Seattle Passenger	Nor. Pac. Grays Harbor Passenger	Nor. Pac. South Bend Passenger	Gt. Nor.	Nor. Pac. Seattle Express	O.-W. R. & N. Seattle Express	Nor. Pac. Freight	O.-W. R. & N. Freight	Nor. Pac. Way Freight	Nor. Pac. Way Freight	Gt. Nor. Way Freight	Nor. Pac. Way Freight				
10.00PM	8.15PM		8.50PM		7.40PM	7.05PM	4.25PM	8.25PM	2.55PM	1.40PM	12.40PM	12.80PM		6.05AM	5.00AM	4.45AM	3.80AM			12.15PM	8.55PM					
9.45 691-679	8.01		8.35 679-691		7.20	7.00	4.05	8.10	2.40	1.20 333-369	12.25	12.10		5.45 965	4.45 965	4.25 965	8.00	8.40	11.40 357	8.80	2.55					
9.87	7.55PM		8.26		7.18	6.87	3.55PM	3.04 966	2.30 365	1.10 311	12.16	12.01PM 357		5.35 997	4.32	4.16	2.50	8.25	11.25	3.20PM 314	2.45 324					
9.80	See page 4		8.17		7.08	6.80	See page 4	2.58	2.17 998 333	1.04	12.05PM 357	See page 4		5.25	4.25	4.09	2.85	8.10	11.00	See page 4	3.33 2.30 358	2.07				
9.20			8.07		6.58	6.22		2.48	2.07	12.55 998	11.54AM			5.08	4.15	3.57	2.21 301 2.05	2.50	10.29 9.28 361 307		1.49 12.45 362 311 369					
9.10			7.57		6.44	6.12 313		2.40 333	1.58 369	12.45	11.48			4.58	4.05	3.47	1.40 1.35 363	2.31 2.26 301	8.55 963		12.25 12.15PM 357					
9.01			7.49		6.34	5.58 359		2.27	1.42 311	12.36 357	11.31			4.37	3.55	3.85	1.05 355 1.00	2.10	8.10		11.55AM					
8.58			7.41		6.27 313	5.48		2.18 369	1.85	12.27	11.21 963			4.26	3.47	3.27	12.40	1.58 1.53 363	7.45		11.40 963					
8.48			7.33		6.16 359	5.38		2.10 311	1.27 357-963	12.18 963	11.11 307 998			4.18	3.88	3.17	12.25 691	1.23 355	7.20 997	361 308 307	11.25 10.35					
8.37			7.26		6.11	5.32		2.02	1.21	12.11PM	11.00			4.04	3.80	3.11	12.01AM	12.58	6.80		10.20					
8.25			7.15	6.55PM	6.00	5.20		1.50	1.10	11.58AM	10.45 10.30		10.05AM	8.45	8.15	2.55	11.40PM 11.05	12.30	6.00AM		10.00 9.25	8.00PM				
8.15			7.00	6.45	5.52	5.08		1.38	1.00	11.45	10.16		9.50	8.35	8.00	2.40	10.50	12.05AM 11.55PM			9.10	2.45				
8.00			6.45	6.40PM 359 See page 6	5.39	4.48		1.18	12.46	11.80	9.55		9.40AM See page 6	8.18	2.45	2.20	8.5	11.85			8.85	2.00				
7.45			6.25		5.27	4.32		1.06 974	12.33 974	11.15	9.43			3.02	2.25	2.00	10.27	11.08			8.00	1.30 12.05PM 358-314				
7.30 313			6.09		5.15	4.19 333		12.58	12.21 307	11.02 361-974 997	9.29			2.47 355	2.07 691	1.40 679 691	9.47	10.48			7.25 973	11.45AM 10.30 362 361 307				
7.25 359			6.02		5.10	4.18		12.47 307	12.15	10.56	9.23			2.40 691	2.00 679	1.80	9.40	10.88			7.05	10.15				
7.20			5.55 333 369		5.06 311 357 369	4.09 311 357 369		12.42 361 997	12.11 973 361 997	10.51 973	9.18			2.35 679	1.55	1.25	10.27	10.88			6.55	10.00 973				
7.10			5.45		4.58	3.58		12.32	12.01PM	10.40	9.08			2.25	1.40	1.15	9.20	10.18			6.40	9.45				
6.55			5.30		4.45	3.45		12.15	11.50AM	10.25	8.52			2.06	1.23	12.58	9.07	9.58			6.10	9.20				
6.50			5.22		4.40	3.39		12.09PM	11.42	10.19	8.45 974			2.00	1.15	12.48	8.45	9.50			6.00	8.08 8.15				
6.37			5.10		4.30	3.27		11.58AM	11.32	10.09	8.33			1.48	12.59	12.38	8.30	9.40			5.40	7.45				
6.30			5.00		4.23	3.19		11.50	11.25	9.59	8.25			1.40	12.49	12.30	8.20	9.30			5.30	7.30 6.80				
6.20			4.50		4.15	3.10		11.40	11.15	9.49	8.16			1.29	12.31	12.17	8.10	9.28			5.10	6.15				
6.11			4.40		4.08	3.01		11.30	11.05	9.41	8.08			1.19	12.21	12.10AM	7.58	9.15			5.00	6.00				
6.00			4.27		3.58	2.51		11.19	10.55	9.31	7.58			1.07	12.10AM	11.59PM	7.45	9.00			4.40	5.45				
5.50			4.16		3.49	2.41		11.08	10.45	9.22	7.48			12.56	11.59PM	11.50	7.34	8.52			4.20	5.27				
5.46			4.12		3.45	2.36		11.04	10.40	9.17	7.44			12.51	11.55	11.46	7.30	8.46			4.15	5.20				
5.42	See Page 5 4.50PM		4.06		3.42	2.31		11.00	10.35	9.13	7.40			12.46	11.50	11.40	7.28	8.39			4.10	5.10				
5.35PM	4.40PM		4.00		3.36	2.25		10.55	10.30AM	9.08	7.35			12.40AM	11.45	11.36	7.15 7.05	8.30			4.00AM	5.00AM				
			3.47		3.30PM 2.18PM			10.47	9.00AM	7.27					11.38	11.30PM	6.55	8.15PM								
			3.45					10.45		7.25					11.31		6.50									
			3.40					10.40		7.20					11.26		6.35									
			3.39					10.39		7.19					11.25		6.34									
			3.35					10.35		7.15					11.20		6.25									
			3.30PM					10.30AM		7.10AM					11.15PM		6.15PM									
DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	DAILY	EX. MON.	EX. SUN.	DAILY	EX. MON.			
4.25	.20	.10	5.20	.15	4.10	4.42	.30	4.55	4.25	4.35	5.30	.29	.25	5.20	5.45	5.10	9.15	7.45	6.15	.41	11.45	10.0				
30.1	24.6	18.6	26.8	20.4	32.4	28.8	16.4	29.1	30.1	29.5	26.0	16.9	12.2	25.0	24.7	26.2	15.5	17.3	8.1	14.0	11.2	8.03				

West Bound

GRAY'S HARBOR LINE

Water, Coal, Scales, Tables and Nyes	Station Numbers	Distance from Lakeview	Time Table No. 35A Succeeding No. 35 November 12, 1911					Capacity of Passing Tracks	FIRST CLASS TRAINS.					SECOND CLASS.			THIRD CLASS TRAINS		
			STATIONS						321	371	365	323	379	585	693	695	965	977	967
			Telegraph Offices and Calls						Nor. Pac. Passenger	O-WRR&N Passenger	Nor. Pac. Passenger	Nor. Pac. Passenger	C.M. & P.S. Passenger	Nor. Pac. Mixed	Nor. Pac. Freight	O-WRR&N Freight	Nor. Pac. Way Frt.	C.M. & P.S. Way Frt.	Nor. Pac. Way Frt.
	1985	0.0	VA..... LAKEVIEW .....	D	100	* 9.20AM		2.15PM	6.01PM							6.10AM			
	CK 2	2.3	..... COUNTRY CLUB .....		No Sdg.	* 9.23		f 2.20	f 6.05										
	CK 3	2.9	..... AMERICAN LAKE .....		40	* 9.24		* 2.21	* 6.06							6.20			
	CK 5	4.3	..... COSGROVE .....		35	* 9.27		f 2.25	f 6.09							6.25			
S	CK 7	8.0	D..... DU PONT .....	D	35	* 9.32		2.35 966	6.16							7.00			
W	CK 13	12.5	..... SHERLOCK .....		25	* 9.42		2.47	6.28							7.20			
	CK 18	17.9	..... UNION MILL .....		Spur	* 9.53		3.00	6.43							7.45			
	CK 20	19.5	..... LACEY .....	T	40	9.55		3.05 324	6.46							7.55			
W T	CK 25	24.5	OY..... OLYMPIA .....	D	110	10.10		3.20	7.00 322							8.15AM 366			
		25.2	PT. TOWNSEND SOUTHERN C'G. (Track Connection)																
	CK 30	29.9	..... BELMORE .....	T	40	* 10.23		f 3.32	f 7.22										
	CK 37	36.4	RK..... LITTLE ROCK .....	D	43	f 10.35 366		3.47	7.38										
		37.7	..... BORDEAUX JUNCTION .....			* 10.38		* 3.49	* 7.40										
	CK 40	39.6	..... MIMA .....		13	* 10.45		f 3.53	f 7.47										
W Y	CK 44	43.7	HK..... GATE .....	D	50	11.00 11.15		4.10 4.15	8.00 8.10										
	CM 5	48.6	OX..... OAKVILLE .....	D	90	11.25		4.26	8.21										
	CM 12	55.5	..... LYTLE .....		80	* 11.38		* 4.42	* 8.36										
W	CM 13	56.6	OR..... PORTER .....	D	20	f 11.40		4.45	8.39										
	CM 19	63.1	EF..... ELMA .....	D	120	11.53 968		5.02	8.55 694										
		65.6	..... MACKS .....			* 11.56		f 5.07	f 9.00										
	CM 23	66.8	SP..... SATSOP .....	D	37	11.59AM		5.11	9.05										
W	CM 29	72.4	MO..... MONTESANO .....	D	70	12.09PM		5.25 322	9.20										
CY	CM 37	81.0	..... ABERDEEN JCT .....	T	42	12.25 324		* 5.45	* 9.48										
	CM 40	84.1	SA..... ABERDEEN .....	D	50	12.40		2.15PM 586	6.00	10.00 9.45	10.25PM								
W C Y	CM 44	87.6	HO..... HOQUIAM .....	D	150	12.55PM 586		2.30PM 604	6.20 6.30	10.30PM 10.00	10.40PM								
	CM 47	90.9	..... GRAYS HARBOR CITY .....		No Sdg.			f 6.40											
	CM 52	95.6	..... GRAY GABLES .....		No Sdg.			f 6.55											
	CM 54	97.0	..... CHENOIS CREEK .....		No Sdg.			f 7.01											
	CM 56	100.2	..... TULIPS .....	T	40			f 7.09											
	CM 61	103.4	..... COPALIS CROSSING .....		Spur			f 7.20											
	CM 62	106.1	..... KUHN .....		No Sdg.			f 7.27											
	CM 63	106.5	..... McGLAUFNIN .....		No Sdg.			f 7.30											
	CM 64	107.7	..... ONSLOW .....		30			f 7.34											
	CM 66	109.5	..... STEARNSVILLE .....		No Sdg.			f 7.39											
	CM 68	111.4	..... ALOHA .....		Spur 12			f 7.45											
W	CM 69	113.2	..... PACIFIC .....		Spur 7			7.50											
	CM 71	114.6	..... SUNSET BEACH .....		No Sdg.			f 7.55											
Y	CM 72	115.6	MC..... MOCLIPS .....	D	40			8.00PM											
			Time Over District			3.35	.15	5.45	4.19	.15						2.05	.30	5.50	
			Average Speed per Hour			24.4	14.0	20.1	20.2	14.0						11.8	7.0	7.5	

East Bound

GRAY'S HARBOR LINE.

Time Table No. 35A  
Succeeding No. 35.  
November 12, 1911

STATIONS. Telegraph Offices and Calls	Distance from Moclips	FIRST CLASS TRAINS.					SECOND CLASS.			THIRD CLASS TRAINS.			
		372	366	380	324	322	586	694	696	978	968	966	
		O-WRR&N Passenger DAILY	Nor. Pac. Passenger DAILY	C.M.&P.S. Passenger DAILY	Nor. Pac. Passenger DAILY	Nor. Pac. Passenger DAILY	Nor. Pac. Mixed EX. SUN.	Nor. Pac. Freight EX. SUN.	O-WRR&N Way Frt.	C.M.&P.S. Freight EX. SUN.	Nor. Pac. Way Frt. EX MON.	Nor. Pac. Way Frt. EX. SUN.	
VA..... LAKEVIEW ..... D	115.6		12.01PM		8.55PM	* 7.55PM						8.20PM	
..... COUNTRY CLUB ..... D	113.3		f 11.54AM		f 8.47	* 7.50							
..... AMERICAN LAKE ..... D	112.7		* 11.58		* 8.46	* 7.49						8.10	
..... COSGROVE ..... D	111.3		f 11.51		f 8.48	* 7.46						8.00	
D..... DU PONT ..... D	107.6		11.46		8.35	f 7.39					365	2.35 2.00	
..... SHERLOCK ..... D	103.1		11.32		8.22	* 7.26						1.26	
..... UNION MILL ..... D	97.7		11.20		8.09	* 7.15						12.46	
..... LACEY ..... T	96.1		11.17		3.05 365	* 7.12						12.26	
OY..... OLYMPIA ..... D	91.1		11.05 11.00 965		2.50 2.45	7.00 6.50 323						12.01PM 366	
PT. TOWNSEND SOUTHERN C'G. (Track Connection)	90.4												
..... BELMORE ..... T	85.7		f 10.47		f 8.34	* 6.40							
RK..... LITTLE ROCK ..... D	79.2		10.35 321		2.20	* 6.28							
..... BORDEAUX JUNCTION ..... D	77.9		* 10.28		* 2.17	* 6.26							
..... MIMA ..... D	76.0		f 10.25		* 2.14	* 6.23		See page 5		See page 5			
HK..... GATE ..... D	71.9		10.15 10.10		2.05 2.00	6.15 6.10		10.10PM		1.30PM			
OX..... OAKVILLE ..... D	67.0		10.00		1.45 967	6.08		9.52		1.15 1.00 967			
..... LYTLE ..... D	60.1		* 9.42		* 1.27	* 5.52		9.24		12.25			
OR..... PORTER ..... D	59.0		9.39		1.25	f 5.50		9.21		12.20PM			
EF..... ELMA ..... D	52.5		9.22		1.09	5.41		323 8.55 8.50		321 11.53AM 11.15			
..... MACKS ..... D	50.0		f 9.14		f 1.01	* 5.37		8.38		11.00			
SP..... SATSOP ..... D	48.8		9.10		12.58	f 5.35		8.35		10.50			
MO..... MONTESANO ..... D	43.2		8.55		12.45	5.25 365		8.20		10.30			
..... ABERDEEN JCT ..... T	34.6		* 8.35		* 12.25 321	* 5.07 967		2.15PM	7.55	9.40			
SA..... ABERDEEN ..... D	31.5	8.05AM	8.25 585	8.50AM	12.15	5.00		2.00PM 1.40	7.30	7.55AM 585	6.50AM	9.10	
HO..... HOQUIAM ..... D	28.0	7.50AM 366	8.10 372	8.35AM 585	12.01PM	4.45PM 997		321 1.30 1.15	7.00PM 365	7.30AM	6.30AM	8.45AM 366 380 585	
..... GRAYS HARBOR CITY ..... D	24.7		f 7.47					12.55					
..... GRAY GABLES ..... D	20.0		f 7.34					12.35					
..... CHENOIS CREEK ..... D	18.6		f 7.26					12.28					
..... TULIPS ..... T	15.4		f 7.20					12.18					
..... COPALIS CROSSING ..... D	12.2		f 7.08					12.01PM					
..... KUHN ..... D	9.5		f 7.01					11.56AM					
..... McGLAUFN ..... D	9.1		f 6.59					11.54					
..... ONSLOW ..... D	7.9		f 6.55					11.50					
..... STEARNSVILLE ..... D	6.1		f 6.50					11.42					
..... ALOHA ..... D	4.2		f 6.42					11.34					
..... PACIFIC ..... D	2.4		6.36					11.28					
..... SUNSET BEACH ..... D	1.0		f 6.33					11.20					
MC..... MOCLIPS ..... D	0.0		6.30AM					11.15					
Time Over District		15	5.31	15	3.10	3.20		3.00	3.10	25	20	5.10	3.19
Average Speed per Hour		14.0	20.9	14.0	27.7	26.3		12.4	13.8	8.3	10.5	8.5	7.3

West Bound. GATE LINE. East Bound. West Bound. OCOSTA BRANCH. East Bound.

Table for GATE LINE, Time Table No. 35A, Succeeding No. 35, November 12, 1911. Columns include Third Class (967), Second Class (693), and First Class (387, 385, 383, 381). Stations include Centralia, Blakeslee, Grand Mound, Rochester, Gate, and Ocosta.

Table for OCOSTA BRANCH, Time Table No. 35A, Succeeding No. 35, November 12, 1911. Columns include Second Class (583, 581) and First Class (582, 584). Stations include Aberdeen Junction, Junction City, Cosmopolis, South Aberdeen, West Aberdeen, South Arbor, Markham, and Ocosta.

Special Rules Gray's Harbor and Gate Line.

See Special Rules, page 6, governing use of double track between Aberdeen and Hoquiam. Registering Stations—Lakeview, Olympia, Gate, Elma, Aberdeen Junction, Aberdeen, Hoquiam and Moclips. Clearance will not be issued at Olympia, Elma and Aberdeen Jct., unless red signal is displayed.

West Bound. YACOLT BRANCH. East Bound.

Table for YACOLT BRANCH, Time Table No. 35A, Succeeding No. 35, November 12, 1911. Columns include First Class (389) and First Class (390). Stations include Yacolt, Wall, Heison, Crawford, Battle Ground, Brush Prairie, Laurin, Homan, Barberton, and Vancouver Junction.

Registering Stations—Yacolt and Vancouver Junction. Bulletin Stations—Vancouver and Yacolt. Standard Clocks—Vancouver. Derail switches located on Daly Spur and on Smith Spur must be kept in derailing position when not in use.

**SPECIAL RULES FOR MAIN LINE.**

Maximum speed of passenger trains is one minute or 60 seconds per mile. This speed must not be exceeded.

**Registering Stations**—Tacoma, Tacoma Wharf, South Tacoma, Tenino, Centralia, Sopenah, Cowlitz, Vancouver and Portland.

Chehalis is registering station for South Bend Branch Trains.

Passenger trains will register by ticket at South Tacoma, Tenino, Sopenah and Cowlitz.

No. 679, No. 680, No. 691, No. 692 and No. 690 will register by ticket at Tenino, Sopenah and Cowlitz.

Trains running via Grays Harbor Line will register at Lakeview.

Clearance will not be issued to west bound trains at Sopenah and to east bound trains at Cowlitz, Tenino or South Tacoma, unless red signal is displayed.

All eastbound trains will procure clearance at Kalama.

At Tacoma and Tacoma Wharf no clearance required.

Engineers will not be required to consult register, except at initial or starting point.

**Bulletin Station**—Tacoma Wharf, Tacoma and Portland (Centralia and Vancouver are bulletin stations for trains originating at those points).

**Standard Clocks**—Tacoma, Centralia, Vancouver and Portland.

Junction switch at east end of Columbia River bridge, Vancouver, will be kept set and locked for N. P. main line.

The movement of trains over Columbia river, Oregon slough and Willamette river draw bridges, between Vancouver and Willbridge, will be governed by interlocking plants, which are operated in accordance with S. P. & S. Interlocking Rules.

Trains and switch engines using track leading to the wharf at Vancouver will come to a full stop before crossing S. P. & S. Ry. crossing, and will not proceed until a flagman has been sent ahead to flag the crossing.

All trains using tracks between Vancouver and Portland will be governed by instructions and card order issued by Superintendent S. P. & S. Ry. at Vancouver. At Vancouver west bound trains will stop at passenger station before engine reaches point of clearance between N. P. & S. P. & S. tracks, and must be under full control before passing station, expecting to find main line occupied.

Conductors and engineers will provide themselves with current time table of Northern Pacific Terminal Co. and will be governed by Special Rules thereon while in Portland Yard. Also provide themselves with current time table of S. P. & S. Railway Co. governing use of tracks between Portland and Vancouver.

Freight trains leaving Tacoma Yard, or switch engines taking transfer to South Tacoma, will not pass crossover track above 15th Street leading from passenger yard to outgoing track without receiving signal from switch tender, who will not allow trains or transfers to pass this crossover when any passenger train is backing out or waiting in the passenger station. East bound trains will be under absolute control approaching Pacific Avenue at Tacoma and will not pass Pacific Avenue crossing without signal from switch tender indicating that crossovers at Pacific Avenue are clear. All trains which will use the Draw Bridge Line at Tacoma without entering passenger station will stop above Pacific Avenue and not proceed beyond there until engineer is furnished with a bridge card and an understanding established with Tower man covering movement of train over Draw Bridge Line. If it is found that freight trains cannot use Draw Bridge Line and passenger train will be delayed on this account, conductor will arrange to enter Half Moon yard and be handled via freight tracks to Tidewater.

Between Tidewater and Tacoma Engineer will obtain card order at Tidewater or Tacoma as authority to use draw-bridge line. Interlocking signals at east and west approach to draw-bridge control use of bridge, and trains will not proceed unless home semaphore shows clear indication.

Westbound trains that do not enter passenger station at Tacoma will leave draw bridge card with tower man at 15th street to be delivered to dispatcher's office.

No engine heavier than N. P. Class "W" loaded weight of which is as follows: Weight on Drivers, 203,000 lbs.; Weight of Engine and Tender, 407,500 lbs. will be run over Bridge No. 254, Tacoma Draw Span.

No two Engines of any class will double head over this bridge where the combined weight is greater than N. P. Class W. Speed of all trains must not exceed ten (10) miles per hour over Tacoma Draw Span.

Engineers will not use sand over derail switches and rail locks east and west end of bridge 254 Tacoma draw span.

Class S or heavier engines must not be used on incline track at Kalama, known as the Salmon track. When doing switching on this track enough cars must be used so that engines will not need to go on this track.

All trains must not exceed ten miles per hour through corporate limits of Roy, Centralia, Chehalis and Winlock, and fifteen miles per hour through corporate limits of Ridgefield.

**Deraill Switches** are located as follows and must be kept set in derailling position when not in use: Tacoma (Harrison Bros. spur); Tacoma (Keystone Lumber Co. spur); Rainier (Bob White Lumber Co. spur); Tenino (Derrickson spur, 2 miles east); Tenino (Stone Quarry); Wabash (Interlocking derail on O.-W. R. & N. Co. connection); Chehalis (east end of house track); Chehalis (west end of flour mill track); Napavine (Sommerville spur and Pitcher's spur); Winlock (west end of house track); Knapps house track.

Tacoma Yard extends to a point 2½ miles west of South Tacoma, and Chehalis Yard to west wye switch at Chehalis Junction. **Centralia yard extends to a point 2500 feet east of Wabash.**

No. 308 will stop at Lakeview to let off passengers from points south of Lakeview. No. 307 will stop at Lakeview on flag to pick up passengers for points south of Lakeview.

Evaline is a flag stop for trains 307, 308, 369, 370, 361 and 362.

No. 334 will stop at McIntosh Saturdays on flag. No. 333 will stop at McIntosh Sundays on flag.

No. 358 and No. 359 will stop on flag at any station between Tacoma and Portland to receive or discharge passengers holding Great Northern tickets reading Spokane or points east thereof.

No. 359 will stop at Tenino to let off passengers from points Tacoma and north, and to pick up Portland passengers.

**Lap Sidings**—Roy and Rainier. Trains taking siding will head in at Lap.

First-class trains when fifteen (15) minutes or more late, and extra trains running on schedule, will observe same precautions in yard limits at Centralia, Chehalis, Kalama, Vancouver and Portland, as are required of second and inferior class trains by Rule 298F.

Telephones are located at Chehalis and Chehalis Junction. All trains from the South Bend line, before leaving Chehalis Junction, will ascertain, by telephone, position of all main line trains, and secure train and block rights authorizing them to use track between Chehalis Junction and Chehalis before proceeding.

Conductors and Engineers must supply themselves with copy of Block Signal Rules governing the use of track between Vancouver and South Tacoma.

Maximum grades, Tacoma Yard office to two and one-half miles west.

Between Centralia and Wabash, the third, or extreme right hand track going east, will be used as a switching lead for the east end of Centralia Yard, as far as the yard limit board; outside of yard limits any trains using this track will obtain train order authority from dispatcher at Tacoma by the use of telephone, which is located in the building formerly used for telegraph office. Communication with the Dispatcher can be had by use of telephone located on the dispatcher's wire, in accordance with the instructions which will be found posted beside the telephone. Under such authority the third track will be used by trains to or from the Centralia Eastern Railway and the Tono Branch of the O.-W. R. & N. Co. at Wabash, and for such east bound main line freight trains as may be designated by Yardmaster, Centralia. No cars will be left on this third track either by train crews or yard crews without train order authority.

**Special Rules Governing Use of Double Track Between Tenino and Sopenah Tillicum and Vancouver and Aberdeen and Hoquiam.**

- (1) Double track extends from a point 400 feet west of depot at Tenino to a point 75 feet west of passenger depot at Sopenah and from Cowlitz to passenger station Vancouver and from double track switch west of passenger station at Aberdeen to double track switch east of the Hoquiam River Draw Bridge, ¾ of a mile east of Hoquiam, except single track across Lewis Bridge, 3.0 miles east of Ridgefield, and single track from west end of passenger station platform at Centralia to a point 1,700 feet west thereof.
  - (2) Trains must keep to the right unless otherwise provided.
  - (3) Before clearing any train entering double track at junction or initial points, or allowing any train to cross over to opposite track for the purpose of running on such track, operators must secure Train Dispatcher's authority.
  - (4) Upon receiving proper block clearance and displaying classification signals, any train may proceed without further orders, inferior class trains keeping clear of first class trains.
  - (5) Any train having work to do, or liable to be delayed by any cause, will report to the Superintendent, and will not occupy the main track on the time of first class trains without permission.
  - (6) When a train crosses over to or obstructs the opposite track, unless otherwise provided, it must first be protected as prescribed by Rule 299 in both directions on that track and permission of Block Operator secured.
  - (7) Work extras must move with current of traffic unless otherwise directed.
  - (8) Any train making reverse movement on double track against the current of traffic must receive either clearance or clearance and caution card at every block office they pass.
  - (9) If a train should part while in motion, the enginemen and trainmen of the front portion must give train parted signal to trains running on the opposite track. A train receiving this signal or being otherwise notified that a train on the opposite track has parted must immediately reduce speed and proceed with caution until the separated train is passed.
  - (10) Caution must be used by engineers of trains approaching stations where any train is receiving or discharging passengers, full stop being made before passing such train. See Rule No. 304, Transportation Rules.
  - (11) To insure personal safety, operators having train orders to deliver to passing trains should stand to the right hand side of train and avoid standing between tracks when possible to do so.
- The single track between depot and the double track switch at Centralia will be operated under Yard Limit rules. Before using single track trains must have time table, or train order rights, or be fully protected by flag. All trains will ascertain position double track switch before using, and will run under full control on the single track between the depot and the double track switch.
- (12) The single track between the double track switch located 800 feet west of passenger station, and the O.-W. R. & N. connection 500 feet east of the passenger station Aberdeen, and the single track between the passenger station at Hoquiam and the double track switch located 500 feet east of the Hoquiam River draw bridge, Hoquiam, will be operated under yard limit rules. Before using single track trains must have time table or train order rights, or be fully protected by flag. All trains will ascertain position of double track switches before using, and will be under full control on the single track at Aberdeen and Hoquiam.
- Trains will be governed by automatic block signals between Tacoma and South Tacoma, and between Kalama and Vancouver. See Special Rules, page 10.

**West Bound.**

**SOUTH BEND BRANCH.**

**East Bound.**

THIRD CLASS.		FIRST CLASS.		Water, Coal, Scales, Tables and Wyes	Station Numbers	Distance from Chehalis Junction	Time Table No. 35A Succeeding No. 85 November 12, 1911.		Distance from South Bend	Capacity of Passing Tracks	FIRST CLASS.		THIRD CLASS.
969	393	391	STATIONS.				392	394			970		
Freight	Passenger	Passenger	Telegraph Offices and Calls								Passenger	Passenger	Freight
See page 1	See page 1	See page 1									See page 2	See page 2	See page 2
EXCEPT SUNDAY	DAILY	DAILY									DAILY	DAILY	EXCEPT SUNDAY
6.45AM	7.50PM	12.30PM	Y	2032	0.0	CHEHALIS JCT.....	3.4	56.5	Y		9.40AM	6.40PM	8.35PM
7.05	8.00	12.40		CW 2	3.4	LITTELL.....D	1.3	53.1	5		9.26	6.30	8.10
7.15	8.03	12.44		CW 5	4.7	ADNA.....	5.4	51.8	37		9.21	6.25	8.25
7.55	8.19	12.58	W	2.4 m West	10.1	CERES.....	6.1	46.4	58		9.06	6.10	1.55
					16.2	LUEDINGHAUS R. R. CROSSING	0.1	40.3					
						No Track Connection							
8.45 8.50 392	8.35	1.15 970		CW 16	16.3	DR.....DRYAD.....D	1.3	40.2	90		8.50 969	5.55	1.15 391
9.05	8.40	1.19		CW 17	17.6	DO.....DOTY.....D	4.7	38.9	Spur		8.45	5.50	1.00
10.15	8.55	1.35	W	CW 22	22.3	PL.....PE ELL.....D	1.4	34.2	75		8.35	5.35	12.30
					23.7	McCORMICK R. R. CROSSING	0.6	32.8					
						Track Connection							
10.35	9.02	1.41	W	CW 24	24.3	McCORMICK.....	1.8	32.2	Spur		8.21	5.27	12.10PM
11.00	9.10	1.50		CW 26	26.1	WALVILLE.....	1.2	30.4	Spur		8.16	5.24	11.55AM
					27.3	WALVILLE R. R. CROSSING	1.6	29.2					
						No Track Connection							
11.40AM 970	9.25	2.00	T	CW 29	28.9	PLUVIUS.....	6.4	27.6	36		8.07	5.17	11.40 969
12.15PM	9.45	2.25	W	CW 35	35.3	FR.....FRANCES.....D	1.3	21.2	35		7.45	4.55	10.20
12.25	9.49	2.30		CW 37	36.6	GLOBE.....	1.4	19.9	Spur		7.39	4.50	9.40
12.35	9.53	2.34		CW 38	38.0	BM.....LEBAM.....D	4.3	18.5	14		7.36	4.47	9.30
1.10	10.03	2.45		CW 42	42.3	HOLCOMB.....	4.2	14.2	30		7.24	4.35	9.00
1.30	10.13	2.58		CW 46	46.5	MENLO.....	4.0	10.0	9		7.13	4.25	8.35
2.00	10.23	3.10	S	CW 50	50.5	WILLAPA.....	2.6	6.0	16		7.02	4.15	8.10
2.30	10.35	3.20		CW 53	53.1	ND.....RAYMOND.....D	3.4	3.4	45		6.57	4.10	8.00
3.00PM 394	10.45PM	3.30PM 394	W C T	CW 57	55.5	SB.....SOUTH BEND.....D		0.0	150		6.45AM	4.00PM 969-391	7.30AM
EXCEPT SUNDAY	DAILY	DAILY									DAILY	DAILY	EXCEPT SUNDAY
8.15	2.55	3.00				Time Over District					2.55	2.40	8.05
6.8	19.3	18.9				Average Speed per Hour					19.3	21.2	6.9

**Registering Stations**—Chehalis and South Bend.

**Standard Clock**—Centralia.

**Bulletin Station**—South Bend.

Speed of passenger trains must not exceed 30 miles per hour, and speed of freight trains must not exceed 20 miles per hour, between Pluvius and Pe Ell.

All trains will stop 400 feet from draw span over South Fork Willapa River, three miles east of South Bend, and will not proceed until draw is known to be closed.

Chehalis Yard includes west "Wye" switch at Chehalis Junction.

Maximum grades between Pe Ell and Frances.

Engineers will not be required to consult register except at initial or starting point.

**Deraill Switches** are located as follows and must be kept in derailling position when not in use: Lebam Mill Spur, Trap Creek Spur, Cram Spur and Wheaton.

Trains from South Bend Branch must ascertain Main Line rights by telephone before occupying Main Line at Chehalis Junction. Nos. 391 and 392 will stop on flag at Trap Creek.

Trap Creek is flag stop for train 393.

West Bound.

BUCKLEY LINE.

East Bound.

West Bound.

GREEN RIVER BRANCH.

East Bound.

Main time table grid for Buckley Line and Green River Branch, including columns for Third Class, First Class, Stations, Distance from Kanaskat, and Average Speed per Hour.

Registering Station.—Kanaskat. Engineers will not be required to consult register except at initial or starting point. Derailing switches west of main line log landings will be set for derail.

Speed of trains over crossover switches at Tidewater and Puyallup and over 15th Street Bridge, entering Tacoma passenger yard, must not exceed ten (10) miles per hour. Trains entering Tacoma Union Station from Tacoma Division Main Line or Draw Bridge Line, will not exceed five miles per hour over switches at the north end of passenger yard, and over switches at Fifteenth street.

Maximum grades, one mile west of Buckley to Cascade Junction. Engines of any class must not be double headed over Bridge 228, Buckley loop, between Cascade Junction and Buckley. No engine heavier than N. P. class "W" loaded weight, of which is as follows. Weight on drivers, 207,000 lbs.; weight of engine and tender, 456,800 lbs will be run over Bridge No. 254, Tacoma Draw Span.



West Bound.		BURNETT BRANCH.		East Bound.	
<b>FIRST CLASS.</b>					
<b>373</b>	<b>375</b>			<b>374</b>	<b>376</b>
Passenger	Passenger			Passenger	Passenger
DAILY	DAILY			DAILY	DAILY
6.21PM	7.26AM			7.25AM	6.20PM
6.26	7.84			7.15	6.15
* 6.81PM*	* 7.89AM*			* 7.10AM*	* 6.10PM*
DAILY	DAILY			DAILY	DAILY
.10	.13			.15	.10
20.4	15.6			18.6	20.4

**Registering Stations.**—Burnett and Cascade Junction. Engineers will not be required to consult register except at initial or starting point. Switches above Burnett will be set to protect cars at quarries by derail. Speed of trains when backing up must not exceed 20 miles per hour. Speed must not exceed six miles per hour within the corporate limits of Burnett. Deraill switch east station platform at Spiketon must be set and locked for derail when not in use.

West Bound.		ORTING BRANCH.		East Bound.	
<b>Time Table No. 35A</b> Succeeding No. 35 November 12, 1911					
<b>STATIONS.</b>					
Telegraph Offices and Calls					
		0.0	END OF TRACK	10.0	
		1.3	TACOMA & EASTERN CROSS'G	8.7	
		2.7	PUYALLUP RIVER	7.3	10
		10.0	ORTING	0.0	200

**Registering Station.**—Orting. Engineers will not be required to consult register except at initial or starting point. Junction switch, one mile east of Orting station will be set for cross-over, and track from cross-over to station will be used as a main line passing track. Maximum grades on St. Paul & Tacoma Lumber Co.'s line east of Puyallup River. See special rules, page 10. Derailling switch 200 feet east of Junction switch must be left set for derail. Deraill at Fisks must be left set for derail.

West Bound.		WILKESON BRANCH.		East Bound.	
<b>FIRST CLASS.</b>					
<b>377</b>				<b>378</b>	
Passenger				Passenger	
DAILY				DAILY	
6.10AM				7.85PM	
6.17				7.80	
6.85				7.15	
6.55				6.55	6.45
* 7.10AM				* 6.81PM	
DAILY				DAILY	
1.00				1.04	
15.5				15.4	

**Maximum Grades.**—Fairfax and Cascade Junction. Engineers will not be required to consult register except at initial or starting point. Derailling switch located 200 feet east of east switch at Montezuma will be kept set and locked for derail. Carbonado Junction switch at Wilkeson and Fairfax Junction switch at Carbonado will be set for Fairfax Line. Speed of trains when backing up must not exceed 20 miles per hour. Trains will stop at railroad crossing near Fairfax Junction, between Carbonado and Fairfax. Deraill switches at west end of coal track at Melmont and 200 feet east of Cascade Junction must be kept set in derailling position when not in use. **Switch east of depot at Fairfax will be set to protect cars at Bunkers by derail.** Trains between Fairfax and Montezuma will look out for logging train of Washington Manufacturing Company, switching at Montezuma. No. 377 has right over No. 378 Fairfax to Cascade Junction.

West Bound.		ELMA BRANCH.		East Bound.	
<b>Time Table No. 35A</b> Succeeding No. 35 November 12, 1911					
<b>STATIONS.</b>					
Telegraph Offices and Calls					
		0.0	SIMPSON	10.0	7
		1.2	SMITHS SPUR	8.8	4
		2.3	HILLGROVE	7.7	4
		2.5	McCLEARY	7.5	8
		5.1	RAYVILLE	4.9	4
		6.0	WHITE'S	4.0	5
		10.0	ELMA	0.0	60

Train service irregular—dependent on amount of business to be handled. **Registering Station.**—Elma. Engineers will not be required to consult register except at initial or starting point. Kraft, 2.0 miles west of Elma, is spur for carload shipments. Note.—All trains will run slow between Simpson and Hillgrove account light rails. Switch in main track just above switch leading to Siding at Simpson must be left to act as derail. See Special Rules, page 10.

West Bound.		CROCKER BRANCH.		East Bound.	
<b>Time Table No. 35A</b> Succeeding No. 35 November 12, 1911					
<b>STATIONS.</b>					
Telegraph Offices and Calls					
		0.0	WINGATE	5.2	140
		5.2	CROCKER	0.0	100

**Registering Station.**—Crocker. Switches below station at Wingate will be set to act as derail. Engineers will not be required to consult register except at initial or starting point. Derailling switches at Crocker and in main track 550 feet west of depot at Wingate, must be left set for derail. See special rules, page 10. Maximum grades.

**COMMERCIAL SPURS.**

MAIN LINE.		MAIN LINE—Cont.		ORTING BRANCH.		BUCKLEY LINE.		GATE LINE—Cont.		SOUTH BEND BRANCH—Cont.		GRAY'S HARBOR LINE.	
DISTANCE FROM TACOMA.				DISTANCE FROM ORTING.		DISTANCE FROM PALMER JCT.				DISTANCE FROM CHEHALIS JC.		DISTANCE FROM LAKEVIEW.	
Stone	37.4	Byckford	53.7	Veneer	3.1	Big 6	1.6	Foran	3.0	Lewis	40.2	Molberg	16.0
Mentzer	38.3	Newaukum	57.6	Fisks	5.2	Occidental	1.8	Duby	12.0	Trap Creek	41.2	Standard Oil Co.	23.4
Tenino Stone Co.	39.5	Evaline	65.0	Dempsey Lumber Co.	8.3	Nolte	1.8	<b>SOUTH BEND BRANCH.</b>		Wheaton	45.0	Black Lake	28.2
Blumauer	40.5	Capitol Mills	69.7	Electron Rock Crusher	8.6	Rosemar	4.0	<b>DISTANCE FROM CHEHALIS JC.</b>		Shore	52.0	Overton	33.4
Great Western Coal Co.	41.3	Metcalf	94.4			Blackburn	11.1	Harmons	6.4	Turney	54.0	Ames	45.6
Martin Lbr. Co.	49.2	Hermione	109.1	<b>WILKESON BRANCH.</b>		Webstone	12.5	Donahue	12.0	Mayfair	55.5	Bagshaw	50.5
Salzer	51.4	<b>CROCKER BRANCH.</b>		<b>DISTANCE FROM CASCADE JCT.</b>		Valley Mill	13.9	Meskill	12.5	<b>YACOLT BRANCH.</b>		Malone	58.1
Carlisle	51.5	<b>DISTANCE FROM CROCKER.</b>		Brierhill Coal & Coke Co.		Broomfield	19.1	Mays	13.0	<b>DISTANCE FROM YACOLT.</b>		Java	60.5
				Wilson's Mill		Firville	22.8	Onn	16.9	McCutcheon	0.9	Vance	64.9
								Cases	27.8	Dole	2.4	Weatherwax	73.9
								Ashlock	28.1	Bouton Perkins	4.7	Ninemire & Morgan	86.4
								Siler	29.6	Lucia	4.9		
								Custer	34.6	Daley	7.9		
								Guerrier	35.0	Smith	10.0		
								Soule	35.8	Tenny	13.2		

**FREIGHT TRAINS AUTHORIZED TO CARRY ADULT MALE PASSENGERS, WHEN PROVIDED WITH PROPER TRANSPORTATION.**

**ORTING LOG TRAIN.**—Between Orting and End of Track on Orting Branch.

**ELMA LOG TRAIN.**—Between Elma and End of Track on Elma Branch.

**OLYMPIA LOG TRAIN.**—Between Olympia and Bordeaux.

**TONNAGE RATINGS—FREIGHT ENGINES—N. P. R. R.**

<b>BUCKLEY LINE—EAST BOUND.</b>																		
	Class Z		Class W		Class Y-5		Class Y-2		Class F-1		Class S		Class E-4		Class E-3 or D-3		Class C-6	
	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars
Tacoma to South Prairie.....			1150	38	1100	37	950	32	900	30	800	27	500	17	475	16	350	12
South Prairie to Buckley.....			600	20	625	21	500	17	450	15	400	14	250	9	235	8	175	6
Buckley to Palmer Jct.....			1100	37	1100	37	900	30	900	30	800	27	500	17	475	16	350	12
Tacoma to South Prairie.....			Maximum 80 Cars		Maximum 80 Cars		Maximum 80 Cars		Maximum 60 Cars		Maximum 80 Cars		Maximum 60 Cars		Maximum 60 Cars		Maximum 40 Cars	
<b>BUCKLEY LINE—WEST BOUND.</b>																		
Palmer to Tacoma.....			Maximum 80 Cars		Maximum 80 Cars		Maximum 80 Cars		Maximum 80 Cars		Maximum 80 Cars		Maximum 60 Cars		Maximum 60 Cars		Maximum 60 Cars	
<b>MAIN LINE—WEST BOUND.</b>																		
GRADES.	Class W		Class Y-2		Class F-1		Class S		Class P		Class E-4		Class E-3		Class D-3		Class C-6	
	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars	Tons	Cars
South Tacoma to Rainier.....	1600	53	1350	45	1200	40	1150	38	1050	35	850	28	825	27	825	27	700	23
Rainier to Chehalis.....		80		80		60		60		60		60		50		50		40
Chehalis to Napavine.....	1200	38	1000	34	900	30	850	28	750	25	550	18	525	17	525	17	400	13
Napavine to Portland.....		80		80	1500	50	2000	60	1400	47	1200	40	1175	39	1175	39	1050	35
<b>MAIN LINE—EAST BOUND.</b>																		
Portland to Winlock.....	1750	58	1550	52	1400	47	1350	45	1250	41	1050	35	1025	34	1025	34	900	30
Winlock to Napavine.....	1260	42	1110	37	1010	33	960	32	860	29	660	22	635	21	635	21	510	17
Napavine to Rainier.....	1500	50	1250	41	1100	36	1050	35	950	31	750	25	725	24	725	24	600	20
Rainier to Tacoma.....		60	1900	63	1750	58	1700	57	1500	50	1300	43	1275	42	1275	42	1150	38

Hereafter the above table of ratings will govern on ruling grades. These ratings are based on a normal number of cars of thirty tons each.

To find the rating of an engine when train contains more or less than normal number of cars, add five tons to the rating of each car less than the normal, and subtract five tons from

the rating for each car in excess of the normal. Maximum eighty cars between Tacoma and Portland.

**Restrictions Governing Class of Power That May be Used on Tacoma Division.**

**Buckley Line.**—All classes except Class Z Mallet Engines.  
**Wilkeson Branch, Cascade Jct. to Wilkeson and Wilkeson to Carbonado.**—No engine heavier than S.  
**Carbonado to Fairfax.**—No engine heavier than F-1.  
**Burnett Branch.**—All classes except Q. T., W X Y and Z.  
**Crocker Branch.**—No engine heavier than F-1.  
**Orting Branch.**—No engine heavier than F-1.  
**Green River Branch.**—No engine heavier than F-1.  
**Main Line.**—All classes except engines heavier than S must not go beyond house track switch leading from log dump track at Felida.  
**Grays Harbor Line, Lakeview to Gate.**—No engine heavier than P compound passenger engine and S at slow speed.  
**Grays Harbor and Gate Line, Gate to Hoquiam.**—No engine heavier than S-4.  
 No engine must be run double header over Satsop river bridge No. 29, and over all Howe truss bridges on Grays Harbor Branch no engines heavier than Class S-4 should be double headed and speed limit of engine's run double header must not exceed eight miles per hour over Howe truss bridges.  
**Grays Harbor Line, Hoquiam to Moclips.**—No engine heavier than F-1.  
**Ocosta Branch, Aberdeen Jct. to Cosmopolis.**—No engine heavier than D-3.  
**Cosmopolis Jct. to Ocosta.**—No engine heavier than mogul.  
**Elma Branch.**—No engine heavier than F-1.  
**South Bend Branch.**—No engine heavier than S, except Draw Span between Raymond and South Bend; no engine heavier than mogul.  
**Yacolt Branch.**—No engine heavier than S-4.  
**Tacoma Drawbridge 254.**  
 No engine heavier than N. P. class W, loaded weights of which is as follows: Weight on drivers, 203,000 lbs.; weight of engine and tender, 407,500 lbs.  
 No two engines of any class will double head over this bridge where combined weight is greater than N. P. Class W.  
 Speed of trains will be restricted to ten (10) miles per hour over this bridge.  
 Double headers will not be run over the following bridges when road engine is heavier than mogul.  
 No. 2 and No. 13 between Centralia and Gate.

**TONNAGE RATING—ENGINES OF O.-W. R. & N. CO. BETWEEN SEATTLE AND PORTLAND.**

Rating of Locomotives in Tons of 2000 Pounds

CLASSIFICATION	Engine Numbers	EAST BOUND							WEST BOUND						
		Portland to Kalama	Kalama to Olequa	Olequa to Winlock	Winlock to Napavine	Centralia to Rainier	Rainier to So. Tacoma	Tacoma to Seattle	Seattle to Tacoma Jct	Tacoma Jct to Tacoma	Tacoma to So. Tacoma	So. Tacoma to Centralia	Centralia to Napavine	Napavine to Portland	
T-63 $\frac{20}{24}$ 113...	136-146.....	1580	1200	990	720	790	1120	1280	1280	655	315	900	655	1580	
	170-207.....	1900	1440	1190	870	960	1310	1540	1540	800	370	1080	800	1900	
T-69 $\frac{22}{28}$ 159...	250-305.....	2200	1680	1380	1000	1110	1560	1790	1790	900	440	1250	900	2200	
C-57 $\frac{15\frac{1}{2} \times 26}{30}$ 176...	330-349.....	2335	1790	1475	1075	1190	1680	1900	1900	985	500	1335	985	2335	
C-57 $\frac{22}{30}$ 187...	350-400.....	2940	2250	1860	1360	1490	2120	2380	2380	1220	560	1680	1220	2940	
Mik-57 $\frac{23\frac{3}{4}}{30}$ 208...	500-540.....	3100	2340	1930	1400	1550	2200	2490	2490	1250	580	1700	1250	3100	
M-63 $\frac{20}{28}$ 147...	C. R. Y. y P. 504-526.	2050	1550	1300	940	1035	1500	1710	1710	840	400	1150	840	2050	
T-57 $\frac{20}{26}$ 132...	720-727.....														
P-77 $\frac{25}{28}$ 170...	208-209.....	2500	1900	1550	1160	1280	1800	2000	2000	1050	500	1420	1050	2500	
S-55 $\frac{19}{26}$ 130...	39-42.....										380				

These ratings include total weight of train, exclusive of engine and tender, which the different classes of locomotives will haul in each direction between the stations shown.

Between stations for which no rating is shown, maximum will apply.

**CLASS**

- "E" —Eight Wheelers
- "A" —Atlantic Type
- "P" —Pacific Type
- "T" —Ten Wheelers
- "M" —Moguls
- "Mik" —Mikado
- "C" —Consolidation Engines
- "TW" —Twelve Wheelers

Example.—Consolidation engine having 57 inch drivers, cylinders 22-inch diameter and 30-inch stroke, and weighing 187,000 pounds on drivers:

C-57  $\frac{22}{30}$  187

Ratings for time freight trains, Albina to Tacoma, is 10% less than tabulated rating as shown between Winlock and Napavine and between Centralia and Rainier.

## RULES GOVERNING AUTOMATIC SIGNALS BETWEEN SOUTH TACOMA AND HALF MOON YARD, TACOMA.

Automatic signals of the three position semaphore type govern East and West bound main line between South Tacoma and Half Moon Yard, Tacoma.

First semaphore on East bound main line is located about 1,500 feet east of passenger station, South Tacoma; the last semaphore before reaching Half Moon Yard, Tacoma, located just east of 15th Street viaduct, and governs the use of track between that point and the overhead bridge at 9th Street; the first semaphore on West bound main line located about 2,000 feet west of the overhead bridge at 11th Street; the last one is located one-half mile east of South Tacoma Station, and governs the use of the track to the South Tacoma Station. The semaphore shows three indications, as follows:

When semaphore arm is 90 degrees upward or light shows green, it indicates "Clear."

When semaphore arm is 45 degrees upward or light shows yellow, it indicates "Caution."

When semaphore arm is at horizontal position or light shows red, it is a signal to stop, block not clear.

All semaphore arms that govern are displayed to the right of signal mast as seen from approaching train. When semaphore arm is in horizontal position or light shows "red," it is a signal to stop, block immediately ahead is occupied. When semaphore is 45 degrees upward or light shows "yellow," it is caution signal, and indicates block immediately ahead is not occupied but next semaphore ahead is at Danger. When semaphore is 90 degrees upward or light shows "green," it indicates that block ahead is clear and the next signal is also clear. Train approaching semaphore and finding it at Danger, will come to full stop, and will proceed under full control, expecting to find block occupied. Train approaching semaphore and finding it at Caution, will proceed, expecting to find next signal in advance at Danger. Train approaching semaphore and finding it at Clear indication, will proceed, expecting to find next signal immediately ahead Clear.

Trains occupying East bound main line between 15th Street viaduct and 9th Street bridge, Half Moon Yard, will hold signal at 15th Street viaduct at Danger. Trains occupying West bound main line between passenger station South Tacoma and the semaphore located one-half mile east, will hold this semaphore at Danger.

All main line switches and both ends of crossover switches within automatic block limits are provided with switch instruments so connected to switch point that the opening of any switch will hold signal of that block at Danger until switch is again closed. The opening of switch at either end of main track crossover will hold signals on both tracks at Danger. If either end of crossover leading to siding is opened, it will hold the signal at Danger that controls block on track to which it is connected. Neither switch or crossover should, therefore, be opened until movement of train is to be made.

Switch indicators of semaphore pattern are located at both ends of crossover switches leading from West bound to East bound main line just east of Pacific Avenue crossing. When indicator arm is in horizontal position it is an indication that block is occupied; when indicator arm is downward it indicates Clear, block not occupied. The opening of either end of crossover switches will set indicator at horizontal or Danger position; in case indicator does not go to Danger when switch points are opened, it is an indication that the signals governing the block have not gone to Danger and that signals are out of order. In such cases movement must be made under protection of flag. Trainmen or yard crews desiring to occupy main line, or to move from West bound track to East bound track, must not open switch leading to that track when indicators show Danger, but must wait until the approaching train shall have passed the switch and out of the block.

If switch indicator shows Danger, provided that after waiting five (5) minutes train does not appear or indicator does not go Clear position, switches may be used provided movement is fully protected by flag.

Passenger trains must not proceed through crossover from Pacific Avenue passenger yard to outgoing main line when block on East bound main line is occupied, until it is positively known that descending train has stopped and will be held above crossovers until passenger train has passed and is clear of the crossover switches.

Cars and engines on side tracks must stand back of insulated joints in order that semaphore will not be held at Danger. Freight trains must clear block before passenger trains are due to enter same. Whenever a train is mentioned in these rules—the term "Train" applies to either a road or switch engine with or without cars. The practice of dumping cinders from engines within automatic block limits is prohibited as it interferes with operation of signals.

The semaphore located at 15th Street on East bound track and the one located one-half mile east of South Tacoma on West bound main track are of the cantilever pattern. These signals are equipped with a bracket upon which is erected a post four feet in length, four inches in diameter. The post is equipped with a yellow light at night, indicating that the semaphore upon which they are attached governs main line and NOT the side track.

Before using the crossover switches above Bailey Street and below Tacoma Avenue, in order to cross over from one Main Line to the other, after throwing the first switch wait three (3) minutes before throwing the next switch and crossing over. This in order to be sure that no train has entered the block before crossover switch had been thrown setting signals at danger.

## RULES GOVERNING AUTOMATIC SIGNALS IN DOUBLE TRACK DISTRICT, BETWEEN KALAMA AND VANCOUVER.

### 1 Indications, automatic signals:

- (A) Semaphore arm in horizontal position or red light by night, STOP.
- (B) Semaphore arm 45 degrees upward, or yellow light by night, CAUTION.
- (C) Semaphore arm 90 degrees upward, or green light by night, CLEAR.

### 2 Governing arm is that seen to the right of the signal mast by approaching train.

3 Trains finding semaphore arm in stop position will, after coming to full stop, proceed with caution, expecting to find train in block, open switch, broken rail, or car foul of the main track.

4 Trains finding semaphore arm at caution will proceed under control, prepared to stop at next signal.

5 Signal light not burning, or white light by night, will be considered a "Stop" signal, and position of signal must be ascertained, and report of circumstances made at next telegraph office.

Indicators of miniature semaphore pattern with push buttons underneath are located at all switches and cross-overs except at Hermione and Knapps, and the house track switch at Ridgefield.

Normal position of indicators is "Stop."

To ascertain whether block is occupied or not, before throwing switch, push the button underneath the indicator. If block is clear when button is pushed, indicator will show clear position and remain in that position as long as pressure is maintained, on the button, and switch should immediately be thrown in order to place signals at stop position. If indicator does not clear when button is pushed, there is a train in the block or approaching, and switch must not be thrown. If indicator cannot be cleared after waiting five (5) minutes and a train does not appear, switches may be used provided movement is fully protected by flag.

Indicators at main track cross-overs show condition of opposite track and not the track on which they are located.

Indicators on side track cross-overs are located on siding end of cross-overs, and indicate condition of main track to which cross-over leads.

Indicators at single switches indicate the condition of track to which switch leads.

Switch instruments are connected to main line switches and both end of cross-over switches within automatic signal limit. The opening of any switch will set and hold signal of that block at "Stop" until switch is again closed. The opening of any switch at either end of main track cross-over will hold signals on both tracks at "Stop." If either end of a siding cross-over is opened, it will set and hold the signal at "stop" that controls block on main track to which it leads. Neither switch or cross-over must, therefore, be opened until movement of train is to be made and must be closed immediately after movement has been made and switches locked. When it is necessary to stop at any signal, stop must be made thirty feet before reaching signal in order not to foul track circuits. Cars and engine on side tracks must stand back of insulated joints in order that signals will not be held at "stop." Whenever a train is mentioned in these rules, the term "train" applies to either a road or switch engine, with or without cars. The practice of dumping cinders from engines within Automatic Block Limits, is prohibited, as it interferes with operation of signals.

Signal 105.8, on east bound track, located 3,000 feet west of Kalama depot, operates in three positions, going to "stop" position when head end of train passes signal, will go to "caution" when the rear of train passes 3,200 feet beyond signal, and will go to "clear" when rear of train has passed a point 200 feet west of east switch of the passing track at Kalama.

Signals governing east bound trains are numbered and located as follows:

### EAST-BOUND FROM VANCOUVER:

133.8—1500 feet east of Mile Post No. 134	119.2—4700 feet east of Mile Post No. 120
133.2—4500 feet east of Mile Post No. 134	117.8—400 feet east of Mile Post No. 118
132.6—2300 feet east of Mile Post No. 133	115.8—900 feet east of Mile Post No. 116
131.4—4800 feet east of Mile Post No. 132	114.6—1600 feet east of Mile Post No. 115
129.8—600 feet east of Mile Post No. 129	113.6—1800 feet east of Mile Post No. 114
127.2—3700 feet east of Mile Post No. 128	112.4—3200 feet east of Mile Post No. 113
125.6—2700 feet east of Mile Post No. 126	110.2—2700 feet east of Mile Post No. 111
123.8—400 feet east of Mile Post No. 124	108.6—2280 feet east of Mile Post No. 109
122.2—4200 feet east of Mile Post No. 123	107.0—4700 feet east of Mile Post No. 108
120.6—2800 feet east of Mile Post No. 121	105.8—2200 feet east of Mile Post No. 106

Signals governing west bound trains, are numbered and located as follows:

### WEST-BOUND FROM KALAMA:

105.7—3400 feet west of Mile Post No. 105	120.7—3200 feet west of Mile Post No. 120
107.1—500 feet west of Mile Post No. 107	122.5—2000 feet west of Mile Post No. 122
108.5—3000 feet west of Mile Post No. 108	123.9—4800 feet west of Mile Post No. 123
110.3—800 feet west of Mile Post No. 110	125.5—2600 feet west of Mile Post No. 125
111.9—3600 feet west of Mile Post No. 111	127.3—1600 feet west of Mile Post No. 127
113.7—3400 feet west of Mile Post No. 113	129.1—400 feet west of Mile Post No. 129
114.7—3600 feet west of Mile Post No. 114	130.7—3800 feet west of Mile Post No. 130
115.9—4400 feet west of Mile Post No. 115	132.3—1800 feet west of Mile Post No. 132
117.9—4800 feet west of Mile Post No. 117	133.3—900 feet west of Mile Post No. 133
119.1—500 feet west of Mile Post No. 119	

Signal No. 133.3, located 5,150 feet east of passenger station, Vancouver, has two positions, viz.: "Danger" and "Caution" and governs use of track to the S. P. & S. connection, just west of passenger station, Vancouver.

East bound track between Vancouver passenger station and signal No. 133.8, 1,850 feet east of station, will be operated under Yard Limit rules.

A train having work to do which may detain it more than ten minutes, must obtain permission from Operator at the last station, before entering the block in which work is to be done.

Operator must obtain authority to give this permission, from the Dispatcher.

Except as affected by these rules, all block signal and train rules, remain in force.

## RULES GOVERNING INTERLOCKING PLANTS LEWIS RIVER DRAW SPAN BETWEEN WOODLAND AND RIDGEFIELD.

Automatic signal No. 115.9 west of Woodland is distant signal on west bound track; signal 117.8, east of Ridgefield, is distant signal on east bound track.

Home signals located 1010 feet from draw span.

Dwarf signals, 660 feet from draw span, between tracks.

Home signals govern as follows:

Upper arm governs trains moving in the direction of traffic, or using the right hand track.

Arm horizontal, stop.

45 degrees upward, caution.

90 degrees upward or vertical, proceed.

Lower arm governs trains moving with traffic to the double track switch and which are to be diverted to the left hand track after crossing bridge, or, slow speed movements with traffic, when for any reason the proper indication cannot be given with the upper arm, in which case position of lower arm will govern. Lower arm has two positions only: Horizontal, stop; 45 degrees upward, caution.

Trains will not run against traffic even though proper signal to do so is received, without regular train order authority.

Under these instructions vertical indication will not be given with both arms of the semaphore at the same time, but engineers

will be governed by the position of the arm which accords with movement they have been authorized to make, whether with or against traffic.

Dwarf Signals, arm horizontal, stop; 45 degrees upward, proceed with caution.

These dwarf signals have only two positions and govern back up movements with or against traffic and govern trains moving against traffic to the double track switch.

Night indications of signals, when displayed on arms governing: Red, stop; yellow, caution; green, proceed; white light, stop (to govern in case of broken lens. A light failure, either a white light or a light extinguished, will be considered stop and reported from first office).

Derails are located 55 feet beyond signals and are open when signals are at danger. Trains must come to a full stop at least thirty feet in advance of signal and wait until either "proceed" or "caution" signal is displayed.

If, for any reason signals become inoperative, trains will proceed after proper hand signals are given and it is known that derails are closed and bridge is clear. Hand signals shall consist of a green flag by day, and a green light by night, and are not to be recognized unless given from track.

Except as noted, the automatic signals between Vancouver and Kalama govern in the direction of traffic only.

## SPECIAL RULES REGARDING USE OF STAFF ON BRANCH LINES.

Du Pont Spur, Elma Branch, Cosmopolis Branch, Hoquiam River Spur, Centralia Eastern, Smelter line at Tacoma, Orting Branch, Crocker Branch and Green River Branch are operated under staff system. Before using these tracks, trains will obtain staff which is located in staff box at each junction. All other trains using these tracks must be operated under protection of flag. For completion

of Dispatcher's record of service, operator at main line junction point will telegraph copy of register showing departure and arrival and mileage made on branch. If there is no operator at junction point, conductor will telegraph this information from next open telegraph office.

## AUTHORIZED SURGEONS, O.-W. R. R. & N. CO.

### SEATTLE—

Dr. Montgomery Russell, Division Surgeon.  
Dr. F. R. Underwood, Assistant Surgeon,  
618-20-22 Leary Bldg.  
District between Seattle and Tacoma.  
Dr. E. B. Burwell, Oculist and Aurist, 300-1  
Cobb Bldg.

### AUBURN—

Dr. F. D. Merritt, District Surgeon.  
District between Seattle and Tacoma.

### TACOMA—

Dr. Chas. James, District Surgeon, 304 Ber-  
lin Bldg.  
District between Auburn and Tenino.

### TENINO—

Dr. Chas. E. Robson, District Surgeon.  
District between Tacoma and Centralia.

### WINLOCK—

Dr. Irvin W. Weichbrod, District Surgeon.  
District between Castle Rock and Centralia.

### CENTRALIA—

Dr. David Livingstone, District Surgeon.  
District between Winlock and Tenino, and  
Elma and Hannaford Creek Branch.

### CASTLE ROCK—

Dr. T. C. Campbell, District Surgeon.  
District between Kelso and Winlock.

### KELSO—

Dr. C. W. Bales, District Surgeon.  
District between Kalama and Castle Rock.

### KALAMA—

Dr. Luther M. Simms, District Surgeon.  
District between Vancouver and Kelso.

### VANCOUVER—

Dr. J. T. Guerin, District Surgeon.  
District between Kalama and Albina.

### ALBINA—

Dr. Curtis C. Holcomb, District Surgeon.  
District between Vancouver and Portland.

### PORTLAND—

Dr. Kenneth A. J. Mackenzie, Chief Sur-  
geon.  
Dr. Geo. Ainslie, Consulting Oculist and  
Aurist.  
Dr. Frank M. Taylor, Assistant Surgeon.  
Dr. D. H. Jessup, Assistant Surgeon.

## AUTHORIZED SURGEONS, N. P. RY. CO.

### Location of Stretchers (S).

<p>Dr. S. W. MOWERS, Chief Surgeon, Western Div., Tacoma.</p> <p>Dr. J. H. SHEETS, Buckley (S).</p> <p>P. B. SWETT, Kangley, Wn.</p>	<p>Dr. W. B. PENNY, Wilkeson, Wn. Ortting (S). Puyallup (S). Tacoma Hospital (S). Tacoma Round House (S). Tacoma Moon Yard Office, (S) Head-of-Bay Yard Office, (S)</p>	<p>Tacoma Baggage Room (S). Tacoma Wharf (S). Tacoma (Toolcar) (S). Dr. P. B. SWEARINGEN, So. Tacoma (S). Dr. E. L. CARLSEN, So. Tacoma (S).</p>	<p>Dr. G. W. KENNICOTT, Chehalis. Dr. J. W. MOWELL, Olympia (S). Dr. J. H. DUMON, Centralia (S). Dr. E. P. FRENCH, Elma. Dr. F. L. CARR, Montesano (S).</p>	<p>Dr. H. C. WATKINS, Hoquiam. Dr. PAUL SMITS, Aberdeen. Dr. A. B. MACLEAN, Pe Ell. Dr. W. GRUWELL, So. Bend (S). Dr. I. A. WEICHBROD, Winlock.</p>	<p>Dr. T. C. CAMPBELL, Castle Rock. Dr. C. A. MACCALLUM, Kalama (S). Dr. J. MCCHESENEY, St. John's. Dr. J. T. GUERIN, Vancouver (S). Dr. ANDREW C. SMITH, Portland (S).</p>	<p>Dr. P. B. WING, Oculist, Tacoma. Dr. W. G. CAMERON, Specialist, Tacoma. Dr. J. F. DICKSON, Oculist, Portland. Dr. A. W. STEVENSON, Yacolt (S).</p>
--	---	--	---	---	---	---

### Note.

**Surgeons** will attend, when called upon officially, to all cases of ACCIDENT occurring to employes or passengers. In cases of SICKNESS it is the intention to limit medical service to the locality or town where a surgeon resides, unless some urgent necessity exists, for which distinct official authority must be had in accordance with established regulations.

**Railway Officials** are required to call on the nearest authorized surgeons whenever practicable, when surgical or medical services are needed. When such are accessible, the Association will not be responsible for bills for medical services rendered by any other physician. In the event of a sudden emergency, arising from accident, if necessary proper surgical aid should be procured until the ar-

rival of a regularly appointed surgeon, when the case should be placed in his charge, and in no case should the services of any but an authorized company surgeon be continued at the expense of the Railway Company or of the Association after such surgeon is able to assume charge of the case.

**Boarding and Nursing** are furnished ONLY AT OUR OWN HOSPITALS. We are not responsible for bills incurred elsewhere unless specially authorized or approved by the Chief Surgeon, and then only in critical cases of injury or illness occurring in the discharge of duty.

## AUTHORIZED SURGEONS, G. N. RY. CO.

Dr. J. A. LA GASA, Tacoma

## TACOMA TERMINAL DIVISION

**Tacoma Terminal embraces Northern Pacific lines from Tidewater at the west line of East "Q" Street to Mile Post 8+942 feet, or approximately 2½ miles west of South Tacoma.**

**Registering Stations.**—Tacoma yard office, Tacoma and South Tacoma.

**Bulletin Stations.**—Tacoma yard office and Tacoma.

**Standard Clock.**—Tacoma.

Passenger trains will register by ticket at South Tacoma. Clearance will not be issued at South Tacoma to east bound trains unless RED signal is displayed. At Tacoma yard office and Tacoma no clearance required.

**Derail Switches** are located as follows, and must be kept set in derailing position when not in use: Harrison Bros. Spur and Keystone Lumber Co. Spur.

Freight trains leaving Tacoma yard, or switch engine taking transfer to South Tacoma, will not pass cross-over track above 15th Street leading from passenger yard to outgoing track without signal from switch tender, who will not allow trains or transfers to pass this cross-over when any passenger train is backing out of or waiting in the passenger station. East bound trains will be under absolute control approaching Pacific Avenue at Tacoma and will not pass Pacific Avenue crossing without signal from switch tender, indicating that cross-overs at Pacific Avenue are clear. All trains which will use the Draw Bridge Line at Tacoma without entering passenger station will stop above Pacific Avenue and not proceed beyond there until engineer is furnished with a bridge card and an understanding established with tower man covering movement of train over Draw Bridge Line. If it is found that freight trains cannot use Draw Bridge Line and passenger train will be delayed on this account, conductor will arrange to enter Half Moon Yard and be handled via freight tracks to Tidewater.

**Maximum Grades.**—Tacoma Yard Office to two and one-half miles west. Speed of trains over cross-over switches at Tidewater and over 15th Street Bridge, entering Tacoma Passenger Yard, must not exceed ten (10) miles per hour, and five (5) miles per hour over switches at north end of passenger yard.

No engine heavier than N. P. class "W," loaded weight of which is as follows—weight on drivers, 207,000 lbs.; weight of engine and tender, 456,800 lbs., will be run over Bridge No. 254, Tacoma Draw Span.

No two engines of any class will double-head over this bridge where the combined weight is greater than N. P. class "W." Speed of all trains must not exceed ten (10) miles per hour over Tacoma Draw Span. Engineers will not use sand over derail switches and rail locks east and west end of Bridge 254, Tacoma draw span.

Trains will keep to the right on double track between Tidewater and Tacoma Wharf and between Tacoma and South Tacoma.

Between Tidewater and Tacoma, engineer will obtain card order at Tidewater or Tacoma as authority to use Draw Bridge Line. Bridge card to be delivered to operator at Tidewater or to Chief Dispatcher at Tacoma. Interlocking signals at east and west approach to Draw Bridge control use of bridge and trains will not proceed unless Home signal shows clear indication. West bound trains that

do not enter passenger station at Tacoma will leave draw bridge card with tower man at 15th street to be delivered to dispatcher's office.

Trains will approach Tidewater under full control and will not proceed until tracks are known to be clear and signal is received from switch tender.

Distance Signal located on drawbridge line 1500 feet east of home signal just east of Tacoma draw span, bridge 254, has been made semi-automatic. When home signal is clear, distance signal will be clear; when home signal shows stop position, distance signal will show stop position. Trains will observe automatic block rules, coming to full stop at distance signal, when same shows stop position, then proceed under full control to home signal.

Trains will approach cross-over switches on double track between Tidewater and Tacoma Wharf located at East L Street (near Head of Bay Yard Office), East D Street (near Round House) and South Twenty-first Street (entering Passenger Station) under full control, and will not proceed until tracks are known to be clear and signal is received from switch tender.

At Tacoma a signal of the single arm semaphore pattern, located near junction of line leading to passenger station and the Draw Bridge Line at 15th Street; another signal of the same pattern at the north end of Passenger Yard. The two signals are to be controlled by switch tender at 15th Street, and will govern single track passenger line between 15th Street and Tacoma passenger station. No train from the Draw Bridge Line or Tacoma Division main line will enter passenger station when signal at 15th Street is at "Danger" and no train will proceed from passenger station yard to Draw Bridge Line or Tacoma Division main line when signal at the north end of yard is at "Danger."

Trains entering passenger station via Head of Bay will use extreme care and not exceed eight (8) miles per hour around curves at south end of passenger yard. As there are no switch tenders at switches at the north end of passenger yard, trains coming into the yard at that point must positively know that switches are lined up for clear track before passing them. Push button operating signal to Tower man will be located on post under Concourse. Switch crew will operate for Portland bound trains and Conductors attend to it for Seattle bound trains.

1st: Engineers will refrain from dumping ash pans on tracks in new passenger station, Tacoma.

2nd: Engineers will reduce exhaust of engine to lowest possible point while passing under concourse Tacoma Union Station.

3rd: Test inspection and understanding as required by Rule 515, Book of Rules of the Operating Department, will be had at South Tacoma, east bound on all freight trains. Conductors will fill out card, form 3632, and deliver same to the Operator at South Tacoma, who will complete and mail to Terminal Superintendent each day. Retainers will be turned up on all cars before descending Tacoma Hill.

4th: Tell-Tales have been placed on train sheds at north and south end of concourse, new passenger Station, Tacoma.

**J. S. DEAN,**  
Train Master, Tacoma

**J. F. ALSIP,**  
Chief Dispatcher, Tacoma