

# **NORTHERN PACIFIC RAILWAY COMPANY.**

**SEATTLE DIVISION**

# **TIME 46 TABLE**

**In Effect at 12:01 A. M. Pacific or 120th Meridian Time.**

**SUNDAY, JUNE 6, 1920.**

**For the Government of Employes only. The Company reserves the right to vary therefrom at pleasure. Be positive that you have the Current Time Table and destroy all previous numbers. Read carefully the Special Rules and always have for reference a copy of TRANSPORTATION RULES.**

**E. C. BLANCHARD,**  
Assistant General Manager.

**J. E. CRAVER,**  
Acting General Superintendent.

**P. H. McCAULEY,**  
Superintendent of Transportation.

**J. E. CAMPBELL,**  
Acting Superintendent.

WESTWARD

FIRST SUBDIVISION (MAIN LINE)

EASTWARD

Table with columns for Third Class, Second Class, First Class, Stations, and Eastward Third Class. Includes train numbers (939, 937, 603, 337, 333, 41, 3, 1, 938, 940), times, and station names like ELLENSBURG, SHOSKIN, THORP, DUDLEY, KOUNTZE, BRISTOL, TEANAWAY, CLE ELUM, BAKER, NELSON, TALMAGE, EASTON, UPHAM, MARTIN, STAMPEDE, BORUP, KENNEDY, LESTER, HOT SPRINGS, MAYWOOD, HUMPHREY, EAGLE GORGE, LEMOLO, PALMER JCT., KANASKAT, BYRD, RAVENSDALE, COVINGTON, WYNACO, EAST AUBURN.

EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION SEE SPECIAL RULES, PAGES 5, 6, 7, 8, 9 and 10.

WESTWARD

SECOND SUBDIVISION (MAIN LINE)

EASTWARD

THIRD CLASS			SECOND CLASS			FIRST CLASS			Time Table No. 46 June 6, 1920 Succeeding No. 45A	STATIONS Telegraph Offices and Calls	FIRST CLASS			SECOND CLASS			THIRD CLASS		
935	927	923	675			443	441	442			444	676			924	928	936		
Way Freight	Way Freight	Way Freight	Freight			Passenger	Passenger	Passenger			Passenger	Freight			Way Freight	Way Freight	Way Freight		
Ex. Sun.	Mo., We., Fri.	Ex. Sun.	Ex. Sat.			Daily	Daily	Daily			Daily	Ex. Sun.			Ex. Mon.	Tu., Thu., Sat.	Ex. Mon.		
		L 8.25AM				L 9.30AM	L 2.20PM			0.0	UD.....SEATTLE.....DN King Street Station	128.0	A 5.30PM	A 12.15PM			A 3.45PM		

BETWEEN KEITH AND SEATTLE TRAINS WILL BE GOVERNED BY PUGET SOUND DIVISION TIME TABLE RULES AND REGULATIONS

		L 9.15AM				L 10.03AM	L 2.53PM	CF 42	12.2	.....KEITH.....	115.8	Spur 13	A 4.57PM	A 11.35AM			A 2.53PM
		s 9.30				f 10.12	f 3.00	CF 46	15.8	.....LAKE.....	112.2	60	f 4.47	f 11.26			s 2.40
		s 9.50		See page 3		s 10.24	s 3.12	CF 53	22.6	B.....BOTHELL.....D	105.4	40	s 4.32	s 11.11	See page 3		s 1.55
L 1.45PM		A 10.00AM			L 9.20PM	s 10.28	s 3.16	WCT CF 55	24.3	CJ....WOODINVILLE....D	103.7	175	s 4.27	s 11.06		A 12.50AM	L 1.50PM
s 2.45		See page 3			10.00	s 10.48	f 3.34	CF 60	30.1	MB.....MALTBY.....D	97.9	77	s 4.13	s 10.48		12.30AM	s 12.01PM
s 3.15 <sup>441</sup>					10.25	A 11.04AM	3.49	C	37.5	.....BROMART.....	90.5	Spur 5	s 3.53	L 10.29AM			4.43
A 4.45PM					A 11.05PM	A 3.50PM	4.42		38.1	HO..G.N.Stn.-Snohomish.DN	89.9	76	L 3.50PM			L 1.40PM	L 7.40AM

BETWEEN SNOHOMISH AND LOWELL TRAINS WILL BE GOVERNED BY GREAT NORTHERN RY. TIME TABLE RULES AND REGULATIONS

L 5.05PM					L 11.20PM		L 3.58PM	BB 6	43.9	W.....LOWELL.....DN	84.1	70	A 3.40PM			A 11.20PM	
A 5.15PM					11.40PM		s 4.02	WCOY BB 8	45.4	EV.....EVERETT.....DN	82.6	100	s 3.29			11.10	
	Via Hartford Line								46.6	PG...G.N.JUNCTION...DN	81.4	No siding					
									46.7	C.M.&St.P.R.R.CROSSING	81.3						
									47.4	C.M.&St.P.R.R.CROSSING	80.6						
					12.15AM		4.10		47.9	.....ROGER.....	80.1	87	3.18			10.55	
					A 12.20AM		A 4.12PM		48.4	WY....DELTA WYE....DN	79.6	No siding	L 3.16PM			L 10.50PM	

BETWEEN DELTA WYE AND KRUSE TRAINS WILL BE GOVERNED BY GREAT NORTHERN RY. TIME TABLE RULES AND REGULATIONS

					L 12.40AM		L 4.26PM		54.4	K.....KRUSE.....DN	73.6	95	A 3.02PM			A 10.30PM	
							f 4.35	W	55.7	.....M.&A.CROSSING....	72.3						
					12.55		s 4.46	Y W M K	58.3	.....EDGECOMB.....	69.7	45	f 2.53	A 9.37AM		10.10	
					s 1.25		s 4.54	CF 91	61.4	A.....ARLINGTON.....DN	66.6	132	s 2.45	s 9.29		s 9.55	
							s 5.12	W	62.6	.....ARLINGTON JUNCTION...D	65.4	No siding					
					1.40		s 5.23	CF 95	65.1	BT.....BRYANT.....D	62.9	72	s 2.35	s 9.17		9.35	
					1.58		s 5.27	CF 101	71.4	MU.....McMURRAY.....D	56.6	65	s 2.22	s 9.03		9.12	
					2.15		f 5.23	CF 107	77.2	.....MONTBORNE.....	50.8	18	f 2.06	s 8.49		8.55	
					2.20		s 5.27	CF 109	78.9	BG.....BIG LAKE.....D	49.1	70	s 2.02	s 8.45		8.45	
					2.37		s 5.40	CF 114	84.3	..P.S.&C.RY.CROSSING..	45.0						
					s 3.10		s 5.48	WCT CF 117	87.5	[WL..SEDRO-WOOLLEY..DN ..TWO G.N.CROSSINGS..] Track Conn. 7.5	40.5	290	s 1.42	s 8.25		s 8.20	
					7.00		6.05	CF 122	95.0	.....THORNWOOD.....	33.0	80	f 1.26	s 8.12		s 3.50	
					s 8.12		s 6.15	Y W	99.3	WK.....WICKERSHAM.....DN	28.7	75	s 1.17	L 8.00AM		s 3.20	
					s 8.50		s 6.30	W	104.2	MC.....ACME.....D	23.8	18	s 1.04			s 2.52	
					s 9.05		f 6.35	CF 133	106.3	.....STANDARD.....	21.7	20	f 12.59			s 2.43	
					s 9.15		s 6.50	CF 141	112.1	DM.....DEMING.....D	15.9	45	s 12.46			s 2.20	
					s 9.40		s 7.10	CF 151	114.2	.....B.&N.RY.CROSSING...D	13.8						
					s 10.05				121.6	NC.....NOOKSACK.....D	6.4	18	s 12.28			s 1.30	
									127.1	.....B.&N.CROSSING....	0.9						
					A 10.30AM		A 7.25PM	WCOT CF 157	129.0	SU.....SUMAS.....D	0.0	110	L 12.15PM			L 1.05PM	
Ex. Sun.	Mo., We., Fri.	Ex. Sun.			Ex. Sat.	Daily	Daily						Daily	Daily		Ex. Sun.	Ex. Mon.
1.45	3.30	.45			8.45	2.42	4.08						4.18	2.43		7.05	1.05
8.7	8.3	16.1			10.5	24.5	25.2						24.2	24.4		12.9	11.2
Time Over Subdivision Average Speed Per Hour																	

EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION

SEE SPECIAL RULES—PAGES 5, 6, 7, 8, 9 AND 10

WESTWARD THIRD SUBDIVISION (ROSLYN BRANCH) EASTWARD

Table for Third Subdivision (Roslyn Branch) showing train schedules for Second Class (477, 475, 473) and Second Class (474, 476, 478). Includes station names like Cle Elum, MINE 5, Roslyn, Ronald, Beekman, Lakedale.

EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION.

Extra trains must wait at Roslyn until second class trains clear at Cle Elum. No. 475 has right over 476 Cle Elum to Beekman. No. 473 has right over 474 Cle Elum to Beekman.

WESTWARD FIFTH SUBDIVISION (SNOQUALMIE BRANCH) EASTWARD

Table for Fifth Subdivision (Snoqualmie Branch) showing train schedules for First Class (923, 445) and First Class (446, 924). Includes station names like Woodinville, Willows, Redmond, Paradise Logg. Ry. Crsq., Campton, Inglewood, Monohon, Issaquah, High Point, Preston, Fall City, Snoqualmie Falls, Snoqualmie, North Bend.

EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION.

Siding located one-half mile east of Preston station is time table station for that point.

WESTWARD FOURTH SUBDIVISION (BELT LINE) EASTWARD

Table for Fourth Subdivision (Belt Line) showing train schedules for Third Class (935), Second Class (675), and First Class (445). Includes station names like Black River, Renton, P. C. R. R. Crossing, S. R. & S. Crossing, Quendall, Wilburton, Northrup, Kirkland, R. R. Crossing, Belt Line Junction, Woodinville.

EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION.

Nos. 445 and 446 will stop on signal at Houghton Crossing. Nos. 445 and 446 register by ticket at Black River. Siding located 600 feet west of Wilburton station is time table station for that point.

WESTWARD SIXTH SUBDIVISION (LOWELL LINE) EASTWARD

Table for Sixth Subdivision (Lowell Line) showing train schedules for First Class (923, 445) and First Class (446, 924). Includes station names like Snohomish, Varden, Ebey Jct., Lowell.

EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION.

**WESTWARD SEVENTH SUBDIVISION (HARTFORD LINE) EASTWARD**

THIRD CLASS		FIRST CLASS		Water, Fuel, Scales, Turn Tables and Wyes	Station Numbers	Distance from Bronart	Time Table No. 46 June 6, 1920 Succeeding No. 45A			Distance from Edgcomb	Car Capacity of Sidings	FIRST CLASS		THIRD CLASS	
927	443	444	928				Passenger	Way Freight	444			928			
Way Freight	Passenger	Passenger	Way Freight				STATIONS								
Mo., We., Fri.	Daily	Daily	Tu., Thu., Sat.				Telegraph Offices and Calls								
L 9.00AM	s 11.10	WOY CF 69	1.2	OM	SNOHOMISH	DN	18.8	150	s 10.25	A 2.45PM					
s 9.25	s 11.20	W CF 74	6.3	MA	MACHIAS	D	13.7	56	s 10.15	s 2.25					
s 10.05	s 11.30	CF 77	9.4	HD	HARTFORD	D	10.6	102	s 10.05	s 2.00					
s 10.25	f 11.42	CF 82	13.9		GETCHELL		6.1	60	s 9.55	s 12.55					
A 10.45AM	A 11.54AM	W CF 88	20.0		EDGEComb		0.0	53	L 9.37AM	L 12.18PM					
Mo., We., Fri.	Daily								Daily	Tu., Thu., Sat.					
1.45	.50														
11.4	24.0														
				Time Over Subdivision				.52							
				Average Speed Per Hour				23.0				7.7			

**EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION.**  
Nos. 443 and 444 will wait 15 minutes at Snohomish for motor connection from Everett.

**WESTWARD EIGHTH SUBDIVISION (DARRINGTON BRANCH) EASTWARD**

SECOND CLASS		Water, Fuel, Scales, Turn Tables and Wyes	Station Numbers	Distance from Darrington	Time Table No. 46 June 6, 1920 Succeeding No. 45A			Distance from Darrington	Car Capacity of Sidings	SECOND CLASS					
469	470				Mixed	470									
Ex. Sun.	Mixed				STATIONS										
L 12.15PM	12.20	C Y ME	0.0		Telegraph Offices and Calls										
s 12.35	s 12.35	W BK 4	5.7		ARLINGTON	DN	28.9	132	A 9.00AM						
s 12.55	s 1.10	BK 7	8.6		ARLINGTON JUNCTION		27.7	No. Siding	s 8.52						
s 1.10	s 1.25	BK 11	12.3		COOPER		23.2	Spur 6	s 8.31						
s 1.25	s 1.35	BK 13	14.3		CICERO		20.3	Spur 2	s 8.20						
s 1.35	s 1.50	BK 15	16.0		OSO	D	16.6	48	s 8.07						
s 1.50	s 2.10	BK 17	18.1		HALTERMAN		14.6	15	s 7.58						
s 2.10	s 2.25	BK 21	21.8		ROWAN		12.9	No. Siding	s 7.51						
s 2.25	s 2.40	BK 22	22.9		HAZEL		10.8	45	s 7.43						
s 2.40	A 2.50PM	BK 24	25.9		FORTSON		7.1	Spur 12	s 7.28						
A 2.50PM	2.35	CY W	28.9		SHEOMET		6.0	Spur 3	s 7.22						
2.35	11.3				GEBBOTT		3.0	Spur 8	s 7.11						
11.3					DARRINGTON	D	0.0	24	L 7.00AM						
				Time Over Subdivision				2.00							
				Average Speed Per Hour				14.5							

**EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION.**

**WESTWARD NINTH SUBDIVISION (BELLINGHAM BRANCH) EASTWARD**

THIRD CLASS		FIRST CLASS		Water, Fuel, Scales, Turn Tables and Wyes	Station Numbers	Distance from Wickersham	Time Table No. 46 June 6, 1920 Succeeding No. 45A			Distance from So. Bellingham	Car Capacity of Sidings	FIRST CLASS		THIRD CLASS	
931	443	444	932				Passenger	Way Freight	444			932			
Way Freight	Passenger	Passenger	Way Freight				STATIONS								
Ex. Sun.	Daily	Daily	Ex. Sun.				Telegraph Offices and Calls								
L 8.00AM	L 1.35PM	Y W	CF 128	0.0	WK	WICKERSHAM	DN	22.5	75	See page 2	A 8.00AM	A 3.35PM			
s 8.15	f 1.42		BM 1	1.3	MIRROR LAKE		21.2	15	f 7.53	s 3.25					
s 8.30	f 1.48		BM 4	3.8	PARK		18.7	15	f 7.44	s 3.15					
s 8.40	f 1.52	W 2, 3, 4	BM 5	4.8	BLUE CANYON		17.7	20	f 7.41	s 3.10					
f	f		BM 9	9.0	TOWANDA		13.5	No Sdg.	f	f					
s 9.05	f 2.14		BM 11	11.4	AGATE BAY		11.1	35	f 7.26	s 2.50					
s 9.20	f 2.25		BM 15	15.1	SILVER BEACH		7.4	No Sdg.	s 7.18	s 2.35					
s 9.25	2.30		BM 16	16.1	LARSON		6.4	30	7.15	s 2.30					
A 10.05AM	A 2.45PM	WYCO	BM 20	20.5	BELLINGHAM	D	2.0	50	L 7.00AM	L 1.40PM					
					G. N. CROSSING		0.6								
					SO. BELLINGHAM	D	0.0	50							
Ex. Sun.	Daily								Daily	Ex. Sun.					
2.05	1.10								1.00	1.55					
9.8	17.6								20.5	10.7					
				Time Over Subdivision				1.00				1.55			
				Average Speed Per Hour				20.5				10.7			

**EASTWARD TRAINS ARE SUPERIOR TO TRAINS OF THE SAME CLASS IN THE OPPOSITE DIRECTION.**  
No. 931 has right over 932 Wickersham to Bellingham.

**COMMERCIAL SPURS.  
FIRST SUBDIVISION.  
Distance from Ellensburg.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Haybow	2.5	1 W	11	Baldi, F 338, 41 & 333	73.3	1 E	8
Swauk	13.5	1 E	3	Headworks	79.2	1 W	7
Casway, F 338 & 333	19.1	1 E	88	Henry's	89.6	1 E	....
Younger	22.4	1 E	10	Newker, F 338 & 333	90.6	1 E	....
Hubner, F 42 & 333	41.0	1 E	....	Cranmar	92.0	1 W	4
Nagrom, F 333, 338, S 41 & 42	65.2	1 W	20	Berrydale	95.6	1 E	9
Forcamp, F 333 & 338	68.4	1 E 1 W	....				

**SECOND SUBDIVISION.  
Distance from King Street Station.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Pontiac, F 443 & 444	12.8	....	....	Chilco	78.4	1 W	7
Hozler	13.0	1 E	3	Nookechamp, F 443 & 444	80.3	....	....
Lavilla, F 443 & 444	14.7	....	....	Tiloh	80.7	1 E	12
Briarcrest, F 443 & 444	17.7	....	....	Forrest Home, F 443 & 444	81.8	....	....
Lake Forest Park, F 443 & 444	18.6	1 W	8	Bradsbury	83.3	1 W	6
Kenmore, F 443 & 444	19.8	1 E	7	Skagit Junction	85.5	1 E	7
Wayne, F 443 & 444	21.8	1 E	3	Delvan, F 443 & 444	89.9	1 E 1 W	....
Hannan	22.2	1 E	14	Norlum Spur	90.3	1 E	Spur
Stockton	23.8	1 E	8	Whitmarsh (on Norlum Spur)	88.1	1 E	....
Bear Creek	26.4	1 E	6	Hoogdale, F 441, 443 & 444	92.2	1 W	4
Grace, F 442, 443 & 444	26.6	....	....	Prairie, S 443 & 444 & F 441	95.8	1 W	....
Cathcart, F 441, 442, 443 & 444	33.7	1 W	12	Morgood	101.1	1 E	3
Cobbner	36.1	1 W	....	Saxon, F 441 & 442	102.1	1 E	6
Madrona	46.2	1 E	Spur	Clipper, F 441 & 442	107.3	1 W	4
Ivanwood	57.2	1 E	....	Pulton	108.0	1 E	4
M. & A. Tfr.	59.7	1 E	....	Coyne	109.2	1 E	9
Grantly	64.5	1 E	15	Van Zandt, F 441 & 442	109.4	1 W	8
Pilchuck, S 441, 442, 443 & 444	66.9	1 E	20	Case, F 441 & 442	110.6	1 E	13
Days F 443 & 444	69.2	Siding	7	Elliton	113.6	1 E	..
Holo	72.5	1 E	....	Lawrence, F 441 & 442	116.3	1 E	6
Ehrlich, F 443 & 444	74.3	1 E	2				

**FOURTH SUBDIVISION.  
Distance from Black River.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Firloch, F 445 & 446	19.8	1 E	3	Hazelwood, F 445 & 446	7.4	....	....
Feriton	16.6	1 E	2	May Creek, F 445 & 446	6.7	1 E	4
Midlakes, F 445 & 446	12.7	1 W	5	Kennydale, F 445 & 446	5.4	....	....
Factoria, F 445 & 446	10.0	....	....	Norco	5.0	1 E	....
Factoria	9.5	1 E	6				

**FIFTH SUBDIVISION.  
Distance from Woodinville.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Hargon	1.7	1 W	7	Lovo	30.8	1 E	15
Hollywood, F 445 & 446	1.9	1 W	19	Niblock	32.5	1 W	100
Samamish, F 445 & 446	9.8	1 E	6	Quariton	34.6	1 E	....
Sulphur Springs, F 445 & 446	13.7	....	....	Tanners	38.1	1 E	9
Pickering, F 445 & 446	17.3	1 E	3	Weeks	38.3	1 E	20
Grand Ridge, F 446	22.0	Siding	15				

**SIXTH SUBDIVISION.  
Distance from Snohomish.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Sherwood	4.2	1 E	4				

**SEVENTH SUBDIVISION.  
Distance from Bromart.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Bartlett	7.1	1 E	4	Harvey	17.7	1 E	4
Lake Cassidy, F 443 & 444	12.6	1 E	3	Sisco, F 443 & 444	18.3	1 E	15

**EIGHTH SUBDIVISION.  
Distance from Arlington.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Trafton	7.6	....	....	Cobridge	24.1	1 E	20
Cavano, S 469 & 470	10.2	Sid'g No. 1 Sid'g No. 3	31 29	Barco	24.6	1 E	20
Dicol	10.4	1 W	9	Wiese	26.5	1 E	20
Tulker	19.2	1 W 1 E	80	Andron	27.9	Wye	....
Lampson	21.4	1 E	4	Giles	29.2	1 W	15

**NINTH SUBDIVISION.  
Distance from Wickersham.**

STATIONS	Miles	How Connected	Car Capacity	STATIONS	Miles	How Connected	Car Capacity
Gale, F 443 & 444	2.6	1 E	5	Jensen	10.0	1 W	4
Sloman	2.7	1 W	29	Mogul Log Co.	14.6	1 E	24
Barker's Camp, F 443 & 444	9.5	....	....	Matson	14.7	1 W	7

**MAXIMUM CLEARANCES**

		LIMIT OF LOAD—MEASUREMENT																Max. Height	Max. Width	
		HEIGHT ABOVE TOP OF RAIL																		
		1 ft. Wide	2 ft. Wide	3 ft. Wide	4 ft. Wide	5 ft. Wide	6 ft. Wide	7 ft. Wide	7 ft. 6 in. Wide	8 ft. Wide	8 ft. 6 in. Wide	9 ft. Wide	9 ft. 6 in. Wide	10 ft. Wide	10 ft. 2 in. Wide	10 ft. 6 in. Wide	11 ft. Wide			11 ft. 6 in. Wide
1st Subdivision	Main Line (Ellensburg-East Auburn)	17' 5"	17' 4"	17' 3"	17' 1"	16' 11"	16' 8"	16' 1"	15' 10"	15' 6"	15' 2"	14' 10"	14' 6"	14' 2"	14' 0"	13' 9"	13' 4"	12' 4"	17' 5"	11' 6"
2nd Subdivision	Main Line (Keith to Sumas)	20' 3"	20' 3"	20' 3"	20' 3"	20' 3"	20' 3"	20' 3"	20' 3"	20' 1"	19' 9"	19' 6"	19' 3"	18' 2"	19' 11"	18' 8"	18' 4"	20' 3"	20' 3"	11' 6"
3rd Subdivision	Roslyn Branch	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	20' 11"	11' 6"
4th Subdivision	Belt Line (Black River-Woodinville)	21' 5"	21' 5"	21' 5"	21' 5"	21' 5"	21' 5"	21' 3"	21' 1"	20' 11"	20' 9"	20' 7"	20' 5"	20' 3"	20' 3"	20' 2"	20' 0"	19' 10"	21' 5"	11' 6"
5th Subdivision	Snoqualmie Branch	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	19' 2"	11' 6"
6th Subdivision	Everett Branch	21' 9"	21' 9"	21' 9"	21' 9"	21' 7"	21' 2"	20' 10"	20' 9"	20' 7"	20' 5"	20' 3"	20' 1"	19' 11"	19' 11"	19' 9"	19' 7"	19' 5"	21' 9"	11' 6"
7th Subdivision	Hartford Line (Bromart-Edgecomb)	21' 3"	21' 3"	21' 3"	21' 3"	21' 3"	21' 3"	21' 2"	21' 0"	20' 10"	20' 8"	20' 6"	20' 4"	20' 2"	20' 2"	20' 0"	19' 10"	19' 8"	21' 3"	11' 6"
8th Subdivision	Darrington Branch	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	18' 10"	11' 6"
9th Subdivision	Bellingham Branch	16' 9"	16' 9"	16' 9"	16' 9"	16' 9"	16' 9"	16' 9"	16' 3"	16' 3"	16' 3"	16' 3"	16' 3"	16' 3"	16' 3"	16' 3"	16' 3"	16' 3"	16' 9"	11' 6"

TONNAGE RATINGS—FREIGHT ENGINES.  
FIRST SUBDIVISION.—EASTWARD.

Table with 23 columns: DISTRICT, Ruling Grade %, Class Z 3, Class Z, Class W 3, Class W, Class Y 5, Class Y 2, Class F 1, Class S, Class E 4, Class E 3 or D 3, Class C 6. Rows include Auburn to Lester, Lester to Easton, and Easton to Ellensburg.

Between Lester and Easton maximum 80 cars.

FIRST SUBDIVISION.—WESTWARD.

Table with 23 columns: DISTRICT, Ruling Grade %, Class E 3, Class E 7, Class F 3, Class F 1, Class S 4, Class W, Class Y 5. Rows include Ellensburg to Easton, Easton to Lester, and Lester to Auburn.

Between Easton and Lester maximum 80 cars.

Large table with 26 columns: DISTRICTS., Ruling Grade %, Class E 3, Class E 7, Class F 3, Class F 1, Class S 4, Class W, Class Y 5. Rows include various subdivisions like Second, Fourth, Fifth, Sixth, Seventh, and Ninth, with specific district names and tonnage/cars ratings.

6/6 71046

**SPECIAL RULES**  
**FIRST SUBDIVISION**  
(Main Line)

**SPEED RESTRICTIONS.**

1. Eastward passenger trains 30 miles per hour between extreme west switch Ellensburg yard and Ellensburg station.
2. Ten miles per hour through incorporated city limits of Cle Elum.
3. Maximum speed of descending passenger trains 30 miles per hour, and descending freight trains 20 miles per hour between Martin and Easton and between Stampede and Lester.
4. Maximum speed of ascending passenger trains 20 miles per hour and ascending freight trains 12 miles per hour between Easton and Martin and between Lester and Stampede as that is the maximum speed that curves are put up for. In case current of traffic is reversed eastward trains using westward track Martin to Easton and westward trains using eastward track Stampede to Lester must particularly observe these restrictions.  
Westward freight trains must use a minimum of 35 minutes, exclusive of all delays, in running between Stampede station and the point where they stop at Lester.
5. Speed of Class W-3, Z and Z-3 engines must not exceed 25 miles per hour at any time; this does not abrogate the 20 miles per hour descending and 12 miles per hour ascending speed restriction of freight trains on Cascade Mountain. Speed of Class W, W-1 and W-2 engines will not exceed 30 miles per hour at any point. This restriction does not abrogate other restrictions of lesser speed governing same class power.  
Speed of Class W-3, Z and Z-3 engines must not exceed 10 miles per hour over the following bridges. This restriction does not abrogate other restrictions of lesser speed:  
Bridge 60, 3d crossing Green River.
7. Speed of all trains through Stampede tunnel No. 3 must not exceed 15 miles per hour and must be so controlled that they can be stopped on emerging.
8. Twenty miles per hour over junction switch at Palmer Junction.
9. Fifteen miles per hour through crossovers and entering sidings.
10. Thirty miles per hour through interlocking plants.
11. Maximum speed of passenger trains is one minute or sixty seconds per mile. This limit must never be exceeded.
12. **Yard Limits**—Ellensburg. Lester.  
Cle Elum. Kanaskat.  
Easton. East Auburn.
13. **Registering Stations**—Ellensburg and East Auburn. At East Auburn all trains register by ticket. Freight trains also register at Auburn Yard. At Easton and Lester trains terminating will register arrival, and at Easton and Lester departing freight trains ascending will register whether "all air" or helper on rear. Palmer Junction is registering station for trains using tenth Subdivision of Tacoma Division only, which will register by ticket.
14. Eastward trains leave register ticket at Lester and procure register check at Easton. Westward trains leave register ticket at Easton and procure register check at Lester.
15. **Bulletin Stations**—Ellensburg and Auburn yard office (Lester and Easton are bulletin stations for enginemen on helper engines).
16. **Standard Clocks**—Ellensburg, Lester and Auburn yard office.
17. **Mountain Grade**—Easton to Lester.
18. **Helper District**—Between Auburn and Easton.
19. Lap Sidings are located at Thorp, Bristol, Teanaway, Nelson, Maywood, Eagle Gorge, Kanaskat and Covington. (Trains taking siding will head in at lap except at Nelson where all trains will head in at the first switch.)
20. Descending freight train must not be permitted to leave Stampede until descending passenger train has arrived at Lester and descending freight train must not be permitted to leave Martin until descending passenger train has arrived at Easton.
21. When block for eastward trains is not clear operator at Martin will head such trains in on eastward siding to enable them to clear Tunnel No. 3.
22. Rule 316 is modified as follows: When the telephone is used, signalmen will transmit the words, represented by the figures.
23. Eastward freight trains will stop clear of the crossover at the water tank at Easton.
24. All sidings between Tunnel No. 3 and westward switches of new sidings west of Tunnel No. 4 will be considered in Stampede station limits, but the old sidings between Tunnels Nos. 3 and 4 must not be used for the meeting or passing of trains.
25. Normal position of double track switches at Easton and Stampede will be for westward trains.
26. Normal position of double track switches at Martin and Lester will be for eastward trains.
27. At Palmer Junction, the upper semaphore arms are train order signals and govern movement of trains via first Subdivision; middle arms are also train order signals and govern movement to and from Tenth Subdivision of Tacoma Division; lower arm is automatic block (west home signal). Switch at Palmer Junction will be set for the First Subdivision line.
28. **Derail switches are located as follows, and must be kept set in derailing position when not in use:**

Ellensburg—East end of east yard.	Lester—West end of roundhouse track.
Ellensburg—Caboose track.	Lester—West end of No. 1 track.
Cle Elum—East end of east extension.	Nagrom—Spur track.
Easton—East end of siding.	For camp—East end west tracks.
Easton—East end of No. 2 track.	Eagle Gorge—West end of Eastward siding and west end of house track.
Easton—East end of interchange track.	Kanaskat—West end of wye.
Stampede—West end of No. 2 track.	Cranmar.
Swauk.	Newker.
Casway.	Berrydale.
Ravensdale—East and west end coal tracks.	

Switch lamps will not be maintained on above switches.

29. Eastward freight trains between Auburn and Stampede and westward freight trains between Easton and Martin using helper power on rear will be governed by following rule: When necessary to take slack to start the train, the engine on rear of train will in all cases take the slack.
30. In order to facilitate the terminal test of air brakes on freight trains at Lester and Easton, as required by Transportation Rule No. 703, engineman who is handling the air brakes will, before the engine is detached to take coal, water, or do station work, make a straight twenty pound reduction from maximum brake pipe pressure with the automatic brake valve. As soon as the brake valve has stopped exhausting, engineman will give one blast of the whistle. Trainmen will not close angle cock to detach engine until this signal is given. Immediately after the brakes have been applied the conductor (or the person whom he may delegate) will make a car to car inspection of the brakes. Defect card form 684, properly filled out, must be attached to any car on which the air brake has failed to apply. This inspection must be completed within fifteen (15) minutes after the brake application. The air must not be coupled into the train from the helper or road engine until the enginemen have been informed that the inspection has been completed. If, for any reason, the road engine is not detached, the brakes must be applied and the test made as outlined above.
31. When a passenger train is furnished two helper engines over Cascade Mountain and one engine is a class "S-4" and the other a class "W," the class "W" engine must be placed on the head and the class "S-4" engine on the rear of train.
32. Westward freight trains consisting of sixty cars or more, regardless whether part empties and part loads, or all empties, or all loads, will use retaining valves on head portion of train between Lester and Auburn as follows:  
Trains of 60 cars will use 12 retainers.  
Trains of 80 cars will use 18 retainers.  
Same to be turned up on cars from the head end alternating by using the retainer on every other car, or the first, third, fifth, etc. On trains containing less than sixty cars, retainers will be furnished by request of the engineman but not to exceed ten on such trains. These retaining valves must be turned down when coming into East Auburn and before engine passes over the hump at bridge between East Auburn and east leg of the wye switch.
33. When two helper engines are coupled together descending on mountain grade, and one engine is not equipped with electric headlight, the engine equipped with the electric headlight must be the leading engine.
34. Electric coal bunker, located on west extension, Cle Elum, will not clear man on side of car or engine, and logs will not be handled on this track.
35. Dead freight trains will fill to tonnage at Cle Elum.
36. No. 338 will connect with No. 596 at Kanaskat.
37. No. 41 will connect with No. 595 at Kanaskat.
38. **When making back-up movement, running test of air brakes must be made from rear of train.**
39. **All toilets in trains must be kept locked while in the limits between Headworks and Humphrey and all employees are cautioned against throwing any refuse or articles, which might become unsanitary, off the train while passing through that territory.**

**AUTOMATIC BLOCK SIGNALS.**

40. It is possible for light engine using cross-over in automatic signal territory to stand between the switches in such a manner as to release the signals when switches are closed. Light engine using cross-overs in automatic signal territory must have at least one switch open while engine is on any part of the cross-over.

**SPECIAL RULES GOVERNING OPERATION OF AUTOMATIC SIGNALS BETWEEN LESTER AND EASTON.**

41. Attention is particularly directed to the signal with two arms, used where traffic is moved in the same direction on parallel tracks shown very plainly in the revised book of transportation rules effective June 1st, 1919, page 134, figure 12. Below find a more detailed explanation of the operation of these signals as to the limits and directions they govern. The automatic signals governing eastward track between Lester and Stampede are operative for eastward trains only. The automatic signals governing the westward track between Stampede and Lester are operative for trains in either direction. Eastward trains holding order to use westward track will be governed by home signal located 1400 feet east of Lester. If train crosses over at Kennedy to eastward track the lower arm of signal located at cross-over governs movement. When both cross-over switches are open this signal will show clear or caution indication if block is not occupied. The automatic signals governing eastward track between Martin and Easton are operative for trains in either direction. Westward trains holding order to use eastward track will be governed by home-signal located 600 feet west of Easton. If train crosses over at cross-over east of tunnel No. 2 the lower arm on signal located at east end of cross-over will govern this movement. When both cross-over switches are open this signal will show clear or caution indication if block is not occupied. The automatic signals governing westward track between Easton and the cross-over at tunnel No. 2 cut are operative for westward trains only. The automatic signals governing westward track between tunnel No. 2 cut and Martin are operative for trains in either direction. Eastward trains holding order to use westward track will be governed by home signal located at east switch at Martin and if has instructions to cross over to eastward track at cross-over east of tunnel No. 2 will be governed by lower arm on signal located at the west end of cross-over. When both cross-over switches are open this signal will show clear or caution indication if block is not occupied. Eastward trains authorized to use the westward track thru to Easton must have train order authority to pass home-signal east of tunnel No. 2. Be referred to page 8, Rule 42, fifth paragraph. Westward freight trains when stopping to make inspection of wheels and brakes at Kennedy will do so with the engine just east of the telegraph office this so as to hold home signal at Stampede at stop until train is past Kennedy.



## SPECIAL RULES—Continued

## 42. FREIGHT TRAIN CONDUCTORS AND ENGINEMEN WILL COMPLY WITH THE FOLLOWING, CONCERNING THE HANDLING OF TRAINS THROUGH TUNNEL No. 3:

On whistling for either Martin or Stampede the engineman must place the handle of the brake valve in full release position and obtain 90 pounds train pipe pressure as promptly as possible. (Engineman must see that low pressure governor head does not exceed 90 pounds.) Following this he must obtain "Proceed" signal before entering tunnel No. 3, to be passed from conductor to head engineman by helper engine whistle and head brakeman. Conductor will not give this signal until the train pipe pressure in the caboose has been increased to at least 80 pounds.

No retaining valves need be used with trains of all empties through tunnel No. 3, but such trains must be stopped and all retaining valves turned up before leaving either Stampede or Martin. With other freight trains, before entering tunnel No. 3 turn up all retaining valves Westward, and all but the rear one-third Eastward, turning all up before leaving Martin.

If for any reason the train breaks in two or more parts while in tunnel No. 3, train and enginemen should arrange to get engines out of tunnel promptly as possible. If necessary, take engines and cars out in either or both directions. When portion of train is left in tunnel, same should be made secure by blocking and not moved out until smoke and gas have cleared and it can be done safely. Blocking will be found on walls of tunnel on right hand side going east, about 100 feet apart and six feet above the rail.

## 43. RULES COVERING THE OPERATION OF SINGLE TRACK BY STAFF SYSTEM BETWEEN STAMPEDE AND MARTIN:

No train, engine, or propelled car will run in either direction until engineman receives from operator a staff which must be retained and delivered to the operator at the opposite end of the block.

The possession of a staff makes the train superior to all other trains between Stampede and Martin.

The eastward train order signal at Stampede, and the westward train order signal at Martin, are interlocked with staff machines located in the telegraph office at Stampede and Martin, and except when used must be set normally at stop and cannot be cleared until the operator at opposite end of block returns staff to machine, which must not be done until rear of train has passed 300 feet beyond the signal. After signal has been cleared for a train entering the tunnel it must be restored to stop immediately after the rear of the train has passed the signal.

In order to use the switches in old Stampede yard, the staff must be used to unlock switch levers with, and

Descending trains will carry 90 pounds train pipe pressure to Lester and to Easton. Following any stops during the descent, the engineman must fully recharge the brakes before starting and the conductor must not give the "Proceed" signal until at least 80 pounds is shown by the caboose gauge.

Eastward freight trains will stop at Lester to make terminal test, and at Easton to make examination of wheels and brakes. Westward freight trains will stop at Easton to make terminal test, and at Lester to make examination of wheels and brakes. In addition to stopping at Lester, westward freight trains will stop at Kennedy (with engine just east of telegraph office) to make inspection of wheels and brakes.

If enginemen handling eastward freight trains find that fan at mouth of tunnel No. 3, Stampede, is in operation when passing vents, train must be stopped at once and engineer in charge of plant notified to stop the fans.

Conductor in charge of freight trains will wire operators at Martin or Stampede, as the case may be, when they have stockmen or messengers or any one legitimately carried on train in excess of regular train crew so that operators can hand up sufficient number of respirators.

levers will have to be returned to normal position before staff can be moved. These tracks cannot be used for trains or engines getting into clear as the staff which is used for unlocking the switches must be returned to machine at Stampede or Martin. (Pusher staff will not unlock switches.)

When a helper engine is used behind caboose, or on rear of passenger train, operators at Stampede will be prepared to deliver pusher staff to engineman. When engine is cut off at old Stampede, the pusher staff will be his authority to return to Stampede. (The pusher staff cannot be put into the machine at Martin, but must be returned to the machine at Stampede.)

In tunnel section between double track switch at Martin and double track switch at Stampede, (A) flagging is not required. (B) Headlight and lighted markers will be used both day and night.

## SPECIAL RULES GOVERNING OPERATION OF TRAINS AND YARD ENGINES BETWEEN EAST AUBURN AND AUBURN AND BETWEEN EAST AUBURN AND AUBURN TRANSFER.

44. Card train order form AB-1740 revised will govern the movement of trains between East Auburn and Auburn and between East Auburn and Auburn Yard, and trains must not move in this territory unless conductor and engineman each holds

a copy properly filled out. Switch engines going around wye upon authority of work order do not need card train order form AB-1740 revised.

## SECOND SUBDIVISION

45. **Registering Stations**—Woodinville, Sedro-Woolley, Wickersham, Everett and Sumas. All trains register by ticket at Kruse and G. N. Station, Snohomish.

46. **Yard Limits**—Woodinville, Maltby, Snohomish, Lowell, Everett, G. N. Junction, Arlington, Sedro-Woolley, Wickersham, Sumas.

47. **Switching Limits**—Territory indicated by signs within which switching will be performed by Yard Crews.

48. **Maximum Grades**—Between Bromart and Woodinville.

49. **Bulletin Stations**—Arlington, Sedro-Woolley, Sumas and Everett.

50. **Standard Clocks**—Sedro-Woolley and Everett.

51. **Helper District**—Between Edgecomb and Arlington, limit 30 cars.

52. **Helper District**—Between Bromart and Woodinville.

53. No. 441 stop at Kruse for passengers destined to points north of Kruse on our own line.

54. **Speed Restrictions**—Fifteen miles per hour through cross overs and entering sidings.

Thirty miles per hour through interlocking plants.

Thirty-five miles per hour around curves on Maltby hill.

Ten miles per hour between Maple Street (located 600 feet east of depot) and Burke Avenue (located 2500 feet west of depot) at Arlington.

Twelve miles per hour between west switch Roger and Delta wye.

Thirty miles per hour at any point of W, W-1 and W-2 engines, this restriction does not abrogate other restrictions of lesser speed.

55. **Clearance Exceptions**—Trains need not obtain clearance at Wickersham, from 9:00 p. m. to 7:00 a. m., unless stop signal is displayed.

56. Engines must not go in beyond 50 feet from frog on Weyerhauser Spur, Everett, account 16-degree curve.

Engines must not go in beyond 10 feet from frog on Brick Spur, Woodinville, account 18-degree curve.

57. Card train order form AB-1740 revised will govern the movement of trains between Lowell and Everett and between Everett and G. N. Junction and trains must not move in this territory unless conductor and engineman each holds a copy properly filled out. N. P. Eastward trains secure card order at Delta Wye authorizing movement from G. N. Jet. to Everett and Westward trains will turn in card authorizing movement Everett to G. N. Jet. at Delta Wye.

58. **Whistle Signals for Delta Wye Interlocker**—N. P. westward trains: one long, one short, one long. N. P. eastward trains: two long, one short, one long.

59. **Normal Position of Main Track Switches**—Bromart and Edgecomb will be for Second Subdivision Main track. Normal position of west siding switch at Kruse and east siding switch at G. N. station Snohomish will be for main track, N. P. trains entering or leaving G. N. main track at these points will go through crossover instead of siding unless otherwise instructed.

Normal position of junction switch at G. N. Junction will be for N. P. main track.

Normal position of main track switch, west of Lowell, will be for G. N. main track.

60. **Derail Switches** are located as follows and must be kept set in derailing position when not in use:

Edgecomb—M. & A. connection.

Arlington—East end of house track.

Arlington—West end of house track.

Arlington—Gravel Pit.

Arlington—Lead track west end.

Bryant—New M. & N. connection.

Bryant—West end siding.

Pilchuck—East end siding.

McMurray—West end log rollway.

Holo—Spur track.

Montborne—East end siding.

Chilco—Spur track.

Clear Lake—West end siding.

Sedro-Woolley—G. N. transfer track.

Sedro-Woolley—Coal bunker track.

Delvan—East end siding.

Thornwood—West end siding.

Hoogdale—Spur.

Prairie—Connection to old line.

Wickersham—Christie's Spur.

Standard—East and west end siding.

61. No engines of any class must go beyond right-of-way line on Clipper Shingle Co.'s track connected from McDonald's Spur.

No engines of any class must use cross-over from Siding No. 1 to Siding No. 2 at Delvan.

Class W or heavier power must not go in on following spurs and tracks:

East end No. 3 track—Arlington.

Tiloh.

Cream and Cannery Spur, and Transfer track—Woolley.

Class S power is also restricted from use of above spurs and tracks, except East End No. 3—Arlington, and may go in as far as bridge at Tiloh.

Class "W" engines cannot turn on table at Woodinville.

## SPECIAL RULES—Continued.

## THIRD SUBDIVISION

## (ROSLYN BRANCH)

63. **Bulletin and Registering Station**—Cle Elum.  
**Maximum Grades**—Cle Elum to Lakedale.  
**Derail Switch**—Cle Elum, upper switch at the head of wye toward Roslyn, will be set for west leg. The derail switch on the main line, nearly in front of scale house at Roslyn, will be left set to act as derail to prevent cars running down main line track toward Cle Elum.  
 No engines of any class must pass under the tipple tracks on the Roslyn Fuel Company's tracks at Beekman.  
 All descending trains must come to full stop 1200 feet west of wye switch and run carefully from that point expecting to find main track occupied.  
**Yard Limits**—Cle Elum.

## FOURTH SUBDIVISION

## (BELT LINE)

64. **Registering Stations**—Woodinville and Black River.  
**Speed Restrictions**—Fifteen miles per hour through cross-overs and entering sidings.  
 Twenty miles per hour Class "W" engines between Black River and Woodinville.  
 All trains send man ahead to line derails and flag across P. C. R. R. crossing at Renton.  
 Engines must not enter Glass Works spur at Renton.  
 Engines must not go beyond frog on S. & R. V. interchange track at Renton account 30° curve.  
 Class "W" or heavier engines must not go beyond frog on coal tracks at Renton.  
 Station at Kirkland is located 2250 feet east of siding.  
**Helper District**—Woodinville to Kirkland, limit 30 cars.  
 Normal position Renton leg wye switch Black River, set for Tacoma leg of wye.  
**Yard Limits**—Renton, Woodinville.

## FIFTH SUBDIVISION

## (SNOQUALMIE BRANCH)

65. **Registering Stations**—Woodinville and North Bend.  
**Maximum Grades**—Issaquah to Preston.  
**Yard Limits**—Woodinville.  
**Speed Restrictions**—Fifteen miles per hour through cross-overs and entering sidings.  
 Twenty miles per hour over truss bridges and high trestles.  
 Ten miles per hour crossing Raging River Bridge.  
 Fifteen miles per hour between Bridge 49 and Snoqualmie Falls.  
 Descending trains must not exceed schedule time on Preston and Fall City grades.  
 All trains leaving Preston must keep at least fifteen minutes apart.  
 Nos. 923 and 924 will carry adult male passengers holding proper transportation between Woodinville and North Bend.  
 Women and children must not be carried on these trains.  
 West wye switch at North Bend will be lined for wye.  
**Derail Switches**—  
 Lovo—Spur.  
 No power heavier than Class "C" engines coupled together may cross Bridge 39 on Fifth Subdivision.  
 No engine heavier than Class "F-1" may be run over Fifth Subdivision.

## SIXTH SUBDIVISION

## (LOWELL LINE)

66. **Registering Station**—Snohomish.  
**Bulletin Station**—Snohomish.  
**Yard Limits**—Snohomish, Lowell.  
**Speed Restrictions**—Fifteen miles per hour through cross-overs and entering sidings. Class "F-1" or heavier engines 15 miles per hour between Snohomish and Lowell. Six miles per hour over Snohomish and Ebey Slough drawbridges.  
 Card train order form A-B 1740 revised will govern the movement of trains between Snohomish and Lowell and trains must not move in this territory unless conductor and engineman each holds a copy properly filled out, operators will not issue cards for steam trains to follow electric trains until electric trains have cleared the block.  
 Look out for trolley wires between tell tales at Snohomish and Ebey Slough bridges. Wires will not clear man on top of box car.  
 No engine heavier than Class "W" may be run over Sixth Subdivision.

## SEVENTH SUBDIVISION

## (HARTFORD LINE)

67. **Registering Station**—Snohomish, except clearance need not be obtained 12:01 a. m. to 8:00 a. m., unless stop signal is displayed.  
**Yard Limits**—Snohomish, Hartford.  
**Bulletin Station**—Snohomish.  
**Helper District**—Between Snohomish and Edgewood, limit 30 cars.  
**Speed Restrictions**—Fifteen miles per hour through crossovers and entering sidings.  
 Passenger trains will not exceed 25 miles per hour, and freight trains 20 miles per hour between Snohomish and Hartford.  
 Class "W" and "Y-2" engines twenty miles per hour between Snohomish and Edgewood.  
 Passing track at Machias is located just west of the station, westward trains taking siding at this point will head in at crossover just west of depot. Eastward trains taking siding will head in at extreme west switch.  
**Derail Switches**—  
 Hartford—East end of passing track.  
 Hartford—East end of house track.  
 Harvey—Spur.  
 All Eastward freight trains will come to full stop at Public Road crossing just east of Hartford station to clear Hartford Eastern Ry. switch and ascertain that track is clear before proceeding.  
 No engine heavier than Class "W" may be run over Seventh Subdivision.

## EIGHTH SUBDIVISION

## (DARRINGTON BRANCH)

68. **Registering Stations**—Arlington and Darrington.  
**Bulletin Station**—Arlington.  
**Speed Restrictions**—Fifteen miles per hour through cross-overs and entering sidings.  
 Move under control where slides and washouts are liable to occur.  
 Track beyond 400 feet from frog on U. S. spur at Darrington is unsafe for engines.  
 Trains handling logs will not exceed ten miles per hour over Howe Truss bridges Nos. 2, 7, 11-1, 18, 19 and 22.  
**Derail Switches**—  
 Cavano—West end.  
 Tulker—East and west ends.  
 Fortson—Spur.  
 Cobridge—Spur.  
 Barco—Spur.  
 Wiese—Spur.  
 Darrington—Gay-Meagher tracks.  
 No engine heavier than Class "F-1" may be run over Eighth Subdivision.  
 No power heavier than Class "C" engines coupled together may be run across Truss Bridges 2, 4, 7, 10, 11-1, 18 and 22 on Eighth Subdivision.

## NINTH SUBDIVISION

## (BELLINGHAM BRANCH)

69. **Registering Stations**—Wickersham and Bellingham.  
**Bulletin Station**—Bellingham.  
**Yard Limits**—Bellingham.  
**Maximum Grades**—Larson to Bellingham and Mirror Lake to Wickersham.  
**Speed Restrictions**—Fifteen miles per hour through cross-overs and entering sidings.  
 Six miles per hour over bridge 20 (Silver Beach).  
 Eight miles per hour over street car crossings at Kentucky Street and between that point and Bellingham depot.  
 Eight miles per hour over street car crossing between Silver Beach and Larson.  
 All trains come to full stop before crossing Holly Street, Bellingham. Flagman precede train with red flag or light.  
 Fifteen miles per hour at any point between M. P. 5 and M. P. 8.  
 Normal position wye switch at Wickersham be set and locked for east leg.  
 Bloedel-Donovan log track at Park outside of right of way not safe for cars or engines.  
**Derail Switches**—  
 Sloman—Spur.  
 Park—Log Spur.  
 Agate Bay—West end siding.  
 Matson—Spur.  
 Larson—East end siding.  
 Bellingham—Rip track.  
 Bellingham—Gas House track.  
 Between Bellingham and South Bellingham 568 feet east of G. N. crossing.  
 No engine heavier than Class "Y-5" may be run over Ninth Subdivision.

## SPECIAL RULES—Continued.

## RAILROAD CROSSING AT GRADE.

70. P. C. R. R. crossing at Renton, P. C. R. R. crossing two miles west of Renton. Campbell Lumber Co. crossing at Campton. Two C. M. & St. P. R. R. crossings between G. N. Junction and Roger. M. & A. crossing 1.3 miles west of Kruse. Two G. N. crossings at Sedro-Woolley. G. N. crossing at E. K. Wood mill, Bellingham. B. & N. crossing just east of Sumas. C. M. & St. P. crossing 300 feet west of Ebey Junction. G. N. crossing 5,000 feet west of Lowell on new Everett freight house track. P. S. & C. Ry. crossing 1.3 miles east of Clear Lake. B. & N. crossing 2.1 miles west of Deming.
71. Crossing Gate situated on new Everett freight house track at crossing of G. N. track located 5,000 feet west of Lowell. Normal position blocks Northern Pacific track. When N. P. trains or engines use this crossing, gate must be unlocked and swung to block G. N. track and locked in that position while crossing is in use, after which gate will be locked in normal position across N. P. tracks.
72. Crossing Gate situated at G. N. crossing near E. K. Wood Mill at South Bellingham. Normal position blocks N. P. track. When N. P. trains or engines use this crossing, gate must be unlocked and swung to block G. N. main line and locked in that position while crossing is in use, after which gate will be locked to normal position across N. P. tracks.
73. Crossing Gate situated where Puget Sound & Baker River Railway Company track crosses N. P. old line just west of Sedro-Woolley. Normal position blocks N. P. track; same procedure as at South Bellingham.
74. **P. C. R. R. Crossing** at Renton is projected by derails located 75 feet east and 75 feet west of the crossing and operated by switch stand between the P. C. R. R. tracks. **NORMAL POSITION OF DERAILS IS AGAINST N. P. TRAINS.** All trains will stop to clear derails, brakeman will go ahead and line up for N. P. track, cross to opposite side of track and remain there until train has cleared both derails; then line back to derail.
75. G. N. crossings at Sedro-Woolley are protected by a hand operated derail, located 200 feet west (Time Table direction) of the most westerly G. N. crossing. This derail must be kept open or in derail position at all times, except when in actual use.
76. B. & N. crossing 2,800 feet West of Mile Post, 113 north of Deming is protected with Cabin Interlocking Plant. Normal position of both home signals will show clear for N. P. trains.

## LOCATION DRAW SPANS.

77. Snohomish River bridge, just east of Snohomish. Skagit River bridge between Sedro-Woolley and Clear Lake. Ebey Slough and Snohomish River bridge on Everett Branch between Snohomish and Lowell. All trains come to full stop before crossing, giving whistle signal before proceeding.

## MISCELLANEOUS RULES.

78. In the State of Washington, conductors of passenger trains consisting of four or more cars, and freight trains consisting of 25 or more cars, must know that brakemen has had at least one year's experience in train-service before assigning them to flagging duties.
79. Trains pulling into side tracks or leaving the main line at junction points must pull entirely into clear main line before stopping to pick up the man attending the switch.
80. Work Train Conductors will instruct their flagmen in writing.

## WATCH INSPECTORS.

HOUGHTON & SON,  
215 Yesler Way,  
Seattle.

F. A. HOME,  
Ellensburg.

J. A. KARTERMAN,  
Cle Elum.

RICHARD VAETH,  
924 Pacific Ave.,  
Tacoma.

ROBERT ANDERSON,  
Everett.

HORACE CONDY,  
Sedro Woolley.

WILBUR GIBBS,  
Bellingham.

E. DEBARTHE,  
Auburn.

## AUTHORIZED SURGEONS, SEATTLE DIVISION.

## LOCATION OF STRETCHERS (S).

DR. P. A. REMINGTON, Chief Surgeon, Western District, Tacoma.

DR. M. F. FROYD, Assistant Chief Surgeon, Western District, Tacoma.

DR. FREDERICK ADAMS, Oculist, Seattle.	DR. C. L. DIXON, Renton.	DR. W. E. GIBSON, Issaquah (S).	DR. J. C. McCAULEY, Ellensburg (S).	DR. F. W. McKNIGHT, Cle Elum (S).	DR. A. E. HILLIS, Oculist, Tacoma.	First aid boxes located at the following points: Bristol, Kanaskat. Eagle Gorge, Ravensdale.
DR. P. W. WILLIS, Seattle.	DR. E. M. ADAMS, Arlington (S).	DR. E. S. CLARK, Sumas (S).	DR. R. R. PINKARD, Ellensburg (S).	DR. B. E. HOYE, Auburn.	DR. W. G. CAMERON, Specialist, Tacoma.	
DR. E. C. GROSS, Seattle.	DR. N. S. McCREADY, Snohomish (S).	DR. R. T. BURKE, North Bend.	DR. R. T. BURKE, North Bend.	DR. W. M. H. BRANDT, Auburn.	DR. W. M. H. BRANDT, Auburn.	
King St. Station, Seattle (S).	DR. W. C. COX, Everett (S).	DR. A. M. SMITH, Bellingham (S).	DR. A. M. SMITH, Bellingham (S).	Auburn Yard Office (S).	N. P. B. A. Hospital, Tacoma (S).	
Yard Office, Seattle (S).	DR. C. C. HARBOUGH, Sedro-Woolley (S).	Woodinville (S).	DR. E. C. HESTON, Roslyn.	Auburn Station (S).	DR. W. B. MERRITT, Kanaskat (Bayne)	
DR. L. J. D. SHULER, Seattle.						

## NOTE.

Surgeons will attend, when called upon officially, to all cases of ACCIDENT occurring to employes or passengers. In cases of SICKNESS it is the intention to limit medical service to the locality or town where a surgeon resides, unless some urgent necessity exists, for which distinct official authority must be had in accordance with established regulations.

Railway Officials are required to call on the nearest authorized surgeons whenever practicable, when surgical or medical services are needed. When such are accessible, the Association will not be responsible for bills for medical services rendered by any other physician. In the event of a sudden emergency, arising from accident, if necessary proper surgical aid should be procured until the arrival of a

regularly appointed surgeon, when the case should be placed in his charge, and in no case should the services of any but an authorized company surgeon be continued at the expense of the Railway Company or of the Association after such surgeon is able to assume charge of the case.

**Boarding and Nursing** are furnished ONLY AT OUR OWN HOSPITALS. We are not responsible for bills incurred elsewhere unless specially authorized or approved by the Chief Surgeon, and then only in critical cases of injury or illness occurring in the discharge of duty.



J. H. ROBINSON,  
Trainmaster, Seattle.  
FRED BRASTRUP,  
Trainmaster, Seattle.

J. F. FITZSIMMONS,  
Trainmaster, Seattle.

W. H. PAGE,  
Trainmaster, Seattle.  
E. H. FRIBERG,  
Chief Dispatcher, Seattle.

FRANK KERGAN . . . Night Chief Dispatcher, Seattle.  
C. J. CHALLAR . . . Asst. Chief Dispatcher, Seattle.  
A. W. ACKLEY . . . Dispatcher, Seattle.  
J. L. BRIMBERRY . . . Dispatcher, Seattle.  
SAMUEL CAMPBELL . . . Dispatcher, Seattle.  
H. R. CHARLTON . . . Dispatcher, Seattle.  
A. B. EMMONS . . . Dispatcher, Seattle.

J. R. GARBER . . . Dispatcher, Seattle.  
J. A. MILLER . . . Dispatcher, Seattle.  
PETER MILLS . . . Dispatcher, Seattle.  
WILLIAM McGEE . . . Dispatcher, Seattle.  
C. F. NASH . . . Dispatcher, Seattle.  
E. M. PRICE . . . Dispatcher, Seattle.  
L. E. WILLIAMS . . . Dispatcher, Seattle.



192 JAN. XVII McGraw-Hill-Warner Co., St. Paul, Minn.